

# field-operator 300

AEROMAT e-motion

Single-grain drill unit



Betriebsanleitung  
Betjeningsvejledning  
Service manual  
Instructions de service  
Manual de usuario



## Revisions

Rev.	Date	Changes	Name
A	21/11/2011	First edition - precision seed drill controller Version: 3.50	H. Blume F. Puder A. Rücker

## Contents

List of diagrams .....	3
Safety instructions .....	4
1.1. Symbols used in the operating manual .....	4
1.2. General safety instructions .....	4
2. Instructions for use .....	5
2.1. Applications .....	5
2.2. Disclaimer .....	5
3. General description .....	6
3.1. Controller configuration .....	6
3.2. Overview .....	6
3.3. Controller technical data .....	7
4. Instructions to follow before start-up .....	8
4.1. Requirements for the ISOBUS job computer assembly location .....	8
4.2. Information about training and induction for operating personnel .....	8
5. Operation .....	9
5.1. Controller start-up instructions .....	9
5.2. Workflow .....	9
5.2.1. Starting the job computer .....	9
5.2.2. Main menu .....	11
5.2.3. Grain spacing menu .....	12



5.2.4.	WORK menu .....	13
5.2.5.	Test menu .....	19
5.2.6.	Data menu .....	22
5.2.7.	SET menu .....	24
5.2.8.	Shutting down .....	28
6.	Maintenance and cleaning .....	29
7.	Warranty.....	29
8.	Manufacturer's declaration.....	30
Appendices .....		31
Appendix 1 – Overview of controller symbols .....		31
Appendix 2 – Quick start guide .....		34

## List of diagrams

Figure 1	Precision seed drill with electrically driven seeder sowing units .....	6
Figure 2:	Field operator 300 .....	9
Figure 3:	Field operator 300 start menu .....	10
Figure 4:	Main menu .....	11
Figure 5:	GRAIN SPACING menu .....	12
Figure 6:	WORK menu .....	13
Figure 7:	WORK TL submenu .....	15
Figure 8:	SET tramline parameters submenu .....	16
Figure 9:	WORK MANUAL TL submenu .....	18
Figure 10:	TEST menu .....	19
Figure 11:	Display of current software versions and motor speeds .....	20
Figure 12:	Motor test run ends .....	20
Figure 13:	GRAIN SENSOR TEST submenu .....	21
Figure 14:	DATA menu.....	22
Figure 15:	CONTRACT ACCOUNT submenu.....	23
Figure 16:	SET menu .....	24
Figure 17:	TECU analogue display .....	25
Figure 18:	100m adjustment start screen .....	26
Figure 19:	100m adjustment trend .....	27
Figure 20:	PERMANENT SHUTDOWN submenu .....	27



## Safety instructions

People who do not understand this manual but are users of the controller are recommended to take an appropriate training course offered by the supplier. If this training is not included in the supplier's services, please contact the manufacturer of the controller. You will find the necessary contact details at the end of this manual.

### 1.1. Symbols used in the operating manual



bodily injuries or



the software.



nputer.

### 1.2. General safety instructions



manual and safety  
them when handling

n to subsequent users



## 2. Instructions for use

### 2.1. Applications

- The controller is used to control the motors of the precision seed drill units for variably adjustable grain spacings with a flexible number of rows (from four to twenty-four).
- The controller is suitable for sowing units of different designs:
  - pneumatic sowing units (overpressure, negative pressure)
  - sowing units with mechanical separation
  - tandem units (pneumatic and mechanical)
- The controller can also operate the following additional equipment:
  - Row marker (hydraulic)
  - Tramline mechanism
  - Pre-emergence markers (hydraulic, electric)
  - Fertiliser spreaders with and without fertilizer flow control
  - Insecticide spreading device
  - Negative pressure control

### 2.2. Disclaimer




sure washer can  
ch cases.

ller components  
anufacturer.



### 3. General description

#### 3.1. Controller configuration



#### 3.2. Overview




Figure 1 Precision seed drill with electrically driven seeder sowing units



- 1 ISOBUS terminal
- 2 ISOBUS job computer
- 3 Distributor
- 4 Motor job computer on the sowing units

### **3.3. Controller technical data**

- Power supply: 10.5 V to 16 V, typically 13.7 V
- Operating temperature: - 20 °C to 70 °C
- Protection class: IP 65
- Power consumption:
  - ISOBUS job computer: approximately 200 mA (complete unit without loads)
  - Motor job computer: approximately 70 mA (without motor)
- ISOBUS job computer inputs/outputs/interfaces:
  - Plug-in socket machine wiring harness
  - 24 motor job computer connections
  - Sensor working position
  - Radar sensor
  - ISOBUS
- Motor job computer inputs/outputs/interfaces:
  - Coupling computer connection
  - Motor output
  - Motor encoder input
  - Tramline marking output
  - Grain sensor input
- ISOBUS terminal hardware requirements:
  - 10 soft keys (minimum requirement)
  - Data mask size 240 x 240 pixels (minimum requirement)
- Emission of airborne noise details: The controller has no influence on Emission noise levels and emission sound pressure levels, since the precision seed drill manufacturer is responsible for the driven noise sources.



## 4. Instructions to follow before start-up

### 4.1. Requirements for the ISOBUS job computer assembly location



You should protect the components of the precision seed drill from the jets of high-pressure cleaners.



Maintain an ambient temperature of – 20°C to 70°C!

### 4.2. Information about training and induction for operating personnel

Operators must be trained and induced in the handling of agro-economic control technology. They should be able to master common terminology. The software manufacturer can offer appropriate training upon request.



## 5. Operation

### 5.1. Controller start-up instructions

The ISOBUS cable and, where required, the duo power cable must be installed in the tractor. The performance of the alternator in the tractor must be capable of meeting the needs of the seed drill.

To protect the controller from damage, the ISOBUS job computer must be cleaned regularly to remove coarse contaminants.

You will find the cleaning Instructions for the ISOBUS job computer in Section 6.

### 5.2. Workflow

1. Start control
2. Main menu
3. GRAIN SPACING menu
4. WORK menu
5. TEST menu
6. DATA menu
7. SET menu

#### 5.2.1. Starting the job computer

The ISOBUS job computer is operated either via the terminal of the WTK-Elektronik GmbH company, the field operator 300,



Figure 2: Field operator 300



... or via a terminal that meets the minimum requirements mentioned in Section 3.3.

The **controller power** is switched on either separately or via the ignition voltage, depending on the specific tractor equipment.

Operation with the "field operator 300" ISOBUS terminal is described below.

### Switching on at the terminal



Press the **START/ON** key to start the controller

### Switching on the ignition


Starting the engine of the vehicle starts the controller automatically.  
The start screen will appear on the terminal display.



Figure 3: Field operator 300 start menu

The symbols that are visible on the left are used to set the tractor and terminal parameters. These symbols are explained in the terminal operating manual.

To start the program, please press the symbol:



Text to the symbol.



The main menu opens.




### 5.2.2. Main menu

The main menu displays the home page of the precision seed drill controller. From here you can, for example, use the WORK menu to monitor the seed drill and set the tramlines.



Figure 4: Main menu

The following menus are available to you to continue:



**GRAIN SPACING menu** - for setting the grain spacing



**WORK menu** - for monitoring the seed and activating the tramlines and row marker



**TEST menu** - for testing the motors and sensors



**DATA menu** - for managing the operating values



**SET menu** - for setting the seed drill parameters



er in the symbol field.





### "Folding frame preselection – right and left"

Assignment of this key is dependent on the machine.

Pressing this button activates the hydraulic valves for moving the folding frame



When the folding frame is activated, the key lights up in green. Activation of the folding frame switches off again automatically after 2 minutes. You can also end the active status of the folding frame by pressing the green **folding frame key** or by



activating the row marker. It is not possible to activate the folding frame and the row marker simultaneously

### 5.2.3. Grain spacing menu

In the GRAIN SPACING menu you can, for example, change the grain spacing quickly for all units.




Figure 5: GRAIN SPACING menu



Use the +/- keys to change the **grain spacing**.



Press the +/- key briefly to change the spacing in steps of 0.2 cm.  
Hold the +/- key down to change the spacing in steps of 1 cm.




Press the **ESC** key to exit the menu



гн.



### 5.2.4. WORK menu



- 1 tramline automatic display [here: on]
- 2 tramline in the pause position
- 3 spread rate (in thousands of grains per ha, a change of one row is made every 5 seconds)
- 4 unit status indicator
- 5 machine setting: [Working position in this case]
- 6 row marker selection [here: left-hand side]
- 7 the speed at which the electric motors are set is displayed. (Source: Seed drill) radar sensor

Figure 6: WORK menu



The available units are shown as symbols and are numbered. Unit 1 is in the left-hand direction of travel.

The status display is only relevant in the working position and shows the work phase for each row of the unit in question.

The status display is shown for the following cycle in working position at the transport position start.



Unit sowing.

In this row, grains are sown in the preset grain spacing.



This row has been switched off by the operator (part width control).

The row will be switched on automatically the next time the operator switches from the working position to the transport position.



This row has been switched off by the automatic tramline system




The tramline was marked out at the beginning of this row.

Grains are being sown



This row has been switched off manually by the operator and will remain off until the operator switches it on again. When the controller is switched off, these settings are lost.





Use the **Unit group change** key to switch between sowing unit groups if the number of units is greater than twelve. If the aggregate number is less than twelve, this key is hidden.



**Row marker key**


Use this key to activate both **row markers**.



Use this key to activate the right-hand **row marker**

The following display then appears on the screen:

The arrow in the display indicates the row marker that is activated. After you press this button, the symbol switches to the key on the row marker at the other side.



**Part width control**; please switch off rows starting from the left.

The rows that are switched off are switched back on again automatically after lifting.



**Part width control**; please switch off rows starting from the right.



Do not press the **Pre-metering key** until the seed drill is in the working position. A starting process is simulated if this function is active. The key lights up green during this process. Pressing the green key stops the starting process.



Press the **Pause key** to stop tramline cycle counting.

The key will then light up red and the following message will appear in the display: **break ON**



The cycle was saved during the pause and will be available again after the system is restarted. If the pause is switched off, the tramlines will be at cycle 1 after the system has been restarted.




The **TRAMLINE menu** opens



Press the **ESC** key to exit the menu.




### WORK TL menu (TRAMLINES)



- 1 status of the automatic tramline system: [here: on]
- 2 Tramline cycle [here: 1 of 10] The tramline rhythm is repeated here after every 10 cycles.
- 3 Seed drill units [Number 1 to 24, from 13 units group must be switched between 2 groups; [Unit 1 is in the left-hand direction of travel]
- 4 Field edge display [here: right]

Figure 7: WORK TL submenu



Press the **automatic tramline system** key to switch on the automatic tramline system. The key will then light up green and "AUTO-TL ON" will appear on the display.



The automatic tramline system will start after the first cycle has been switched on.


The seed drill machine controller calculates the tramlines according to the parameters set in the SET-TL menu and controls the units accordingly.




#### Increasing/decreasing the tramline cycle

Press the **+/- keys** to increase [+] or decrease [-] the tramline cycle manually.

**Preview:** Press the keys several times consecutively to see a preview of the next row.



Press this key to reset the preview to **Tramline on the first cycle**.



Press the **Field edge key** to enter the side of the field on which the field edge is located. The controller will automatically continue counting in the subsequent rows. In the figure, the current field edge position is displayed as a green vertical bar.



› the transport  
cycle counting  
valid for the





The SET TL menu opens

### SET TL menu

In the SET TL menu, you can set the parameters needed for automatic tramline calculation.




Figure 8: SET tramline parameters submenu



### Numeric entry on fo300

You can use the up/down arrow keys to select entry fields, so that the frame (yellow dotted line) marks the entry field.

There are two options for making numeric entries:

a) Using the numeric keys to enter the digits directly. When you do so, the previous number will be overwritten. Alternatively, you can use the right/left arrow keys links to select a digit, with which you can then overwrite a numeric key individually. A red dotted line around the entry field indicates that entries are active.

b) Use the plus and minus keys to adjust the numerical value up or down in steps (the entry is only valid if there is no red dotted line round the entry field).

In entry fields marked with the input list character  $\updownarrow$ , only the plus and minus keys can be used to make entries. A red dotted line around the entry field indicates that entries are active.

The input value (red dotted line around the entry field) must be confirmed by pressing ENTER or by using the up/down arrow keys.



# Operating manual Controller for precision seed drill



The following parameters are adjustable:

<b>Cultivation width:</b>	working width of the cultivation unit (e.g. sprays) (adjustable from 10 to 99.9 m in steps of 0.1 m)
<b>Track width:</b>	cultivation unit to track width (adjustable from: 1.50 m to 2.50 m in steps of 0.05 m)
<b>Field edge:</b>	Side on which the edge of the field is located at the start of sowing
<b>Tyre width:</b>	Tyre width of the cultivation vehicle (adjustable from 10 to 149 cm in steps of 1 cm)
<b>Minimum distance to Plant:</b>	Safety distance between tyre edge and the plant (adjustable from 00 to 18 cm in steps of 1 cm)
<b>Mark out TL:</b>	Switches tramline marking out function on and off. When the tramline marking out function is switched on, the motors are stopped at the first 10 m after the seed drill has been lowered. At the end of the row, the driver must press the "Mark out tramline" key to stop the motors for the remaining distance.



es are calculated.  
/ in the adjacent

## Grain density

The percentage entered in the "increase" field expresses the percentage by which the grain density in the adjacent rows of the automatically calculated or manually switched tramlines should be increased. If "Mark out TL" is in the "ON" position, the increase only applies to manually switched tramlines.

## Auxiliary Manual TL

For manually switched rows (WORK manual TL), the decision is made here as to whether or not the grain density in the adjacent ROWS should be increased. Use the +/- keys to switch between "ON" and "OFF".

## Increase:

Enter the percentage by which the grain density in the adjacent tramline rows (does not apply to marked out TL) should be increased (adjustable from 0 to 99 in steps of 1%).




is switched off  
ain density  
een reduced by  
rows. The  
ning the



**ESC** Press the ESC key to exit the menu. The WORK TL menu opens

 The **WORK MANUAL TL** menu opens


### WORK MANUAL TL menu




menu.


1



2




3



**WORK/TRAM LINES MANUAL**

AUTOTRAM on 3 / 14 13.2cm  
100120Grains/ha

Row: 1 100.1TGrains/ha

1	2	3	4	5	6	7	8	9	10	11	12
											

6.6 km/h

Do 20.10.11 09:05


**ESC**

1 Cursor

2 switched off row,  
unit has been switched off manually.



3 tramline display,  
unit has been switched off by the  
automatic tramline system.

Figure 9: WORK MANUAL TL submenu





individual rows on  
until they are  
ncrease for the  
ied off rows are

Press the **arrow keys** to flag individual units for switching on or off.





d by the

l by the

utomatically





tramline  
-].




units on or off



### 5.2.5. Test menu

In the TEST menu, you can use 2 options to test the motors and check the software version of the connected job computer. You can also test the grain sensors, blower sensor and fertilisation wave sensor.



- 1 ISOBUS job computer software version
- 2 LIN job computer software version
- 3 Motor job computer software version
- 4 Blower speed in rpm (option)

Figure 10: TEST menu



manufacturer  
lease the



units if there are



eed drill into  
.  
it it is running





Press the **Run** key to start automatic testing of all motors. The following menu appears:








Figure 11: Display of current software versions and motor speeds

If necessary, use  to pause the sequence. Then use  to continue the sequence or  to end it early.

The following menu appears after the motor test run:



- 1 Motor running correctly
- 2 Error message on motor 2

Figure 12: Motor test run ends



Press the ACK key to acknowledge the results.

Both test motor variants allow you to specify the speed of each motor so that you can test its function. The information contained in the SET parameters, such as grain spacing and cell numbers, are taken into account with the motor speed. The motor speed is given under the unit as a number in 10 revolutions per minute.



The speed you at which you want to set the motor must be entered in the "Simulation speed." field (do not forget to press ENTER). The motors will then begin running as soon as the "Simulation speed." has been set using the cursor.



eed to units.



### GRAIN SENSOR TEST menu



Figure 13: GRAIN SENSOR TEST submenu



eam on the grain

alling grain, a beep is  
/.





5.2.6. Data menu

In the DATA menu, you can view the operating parameters such as surface area and hours on the counter and measure them using a section counter. You can also manage the operating values in 8 accounts.





Figure 14: DATA menu



to calculate the surface  
ation.  
e has operated in the



re area covered



re one active account..





CONTRACT ACCOUNT menu




Figure 15: CONTRACT ACCOUNT submenu





me is saved in



is saved in the  
and displayed.



display will  
1.









## 5.2.7. SET menu

In the SET menu, you can set the machine-specific values. These values must be entered and will remain in memory until you overwrite them.




Figure 16: SET menu

The following parameters are adjustable:

**Grain spacing:**

**Number of rows:**

**Number radar pulses/m:**

**Holes per seed plate:**

se the +/- keys to adjust  
until the next time  
3.  
terminal to move



but it can be

**Row spacing:**

**Grain-alarm threshold:**

**Fert. shaft monitoring:**

ues. The values will  
he arrow keys on the  
re values.



els.  
lease select "OFF".



# Operating manual Controller for precision seed drill



## Air blower-alarm:

ver monitoring on the +/-  
terminal to confirm.  
ctivated on all models. If  
it will not appear on your

## Working pos.:

on about whether or  
ious options are

nstalled on the seed



you can choose

**TECU-digit.**

delayed start: 0,1s

in be set (in steps of 0.1  
emission on the  
:hine controller.

**TECU-ana**

angle representing the  
nsport position of the  
age).




Figure 17: TECU analogue display



# Operating manual Controller for precision seed drill



oint.




## 100m adjustment



	d, surface area rit.
	layed speed

### Procedure:



Measure a distance of 100 m in the field.  
Mark the start and finish lines.  
Move the seed drill into the operating position  
and travel in the start direction at working  
speed.  
Press the key while you are crossing the start  
line.



Figure 18: 100m adjustment start screen






Figure 19: 100m adjustment trend

### Permanent shutdown submenu

In the permanent shutdown submenu, you can switch off individual units or all units manually at the same time.




Figure 20: PERMANENT SHUTDOWN submenu



When settings, this

will appear.




Enter the row spacing.





Press the **Unit ON/OFF key** to switch off individual units permanently.



Press the **General unit ON/OFF key** to switch off all units permanently.



Use the **arrow key** to move between rows.



### 5.2.8. Shutting down



Use the **start key** was used  
in the ignition.)



Use the **seed drill**  
condition.



## 6. Maintenance and cleaning



Switch off the ISOBUS job computer whenever maintenance and repair work must be carried out on the machine!  
Only carry out **electrical welding work** on the machine or attachments **when the mains power supply to the terminal is switched off.**



You should protect the components of the precision seed drill from the jets of high pressure cleaners.

## 7. Warranty

If you have legitimate complaints about the controller, you should contact your seed drill manufacturer.

The manufacturer shall accept no liability in the event of damage owing to failure to comply with these instructions.



## 8. Manufacturer's declaration

WTK-Elektronik GmbH hereby declares that the

**WTK precision seed drill controller** complies with the essential requirements of the Electromagnetic Compatibility Act (EMVG).

The basis of this law is Directive 2004/108/EC of 15/ 12/2004.

The product standard used as for testing is:

- DIN\_EN ISO 14982 agricultural and forestry machinery, electromagnetic compatibility, testing procedures and assessment criteria

with testing of:

- Fault-free operation:
  - Conducted disturbances (test pulses 1,2,3 a, 3b, 4,5 pursuant to ISO 7637-1)
  - Immunity to the narrowband RF field pursuant to DIN EN ISO 14982
- Interference emission:
  - Electromagnetic interference emission pursuant to DIN-EN ISO 14982.

### WTK ELEKTRONIK GmbH

Bischofswerdaer Str. 37f.  
01844 Neustadt

Contact:

Dr. Matthias Pallmer

Tel. +49 3596 5656-22

















Fax +49 3596 5656-14

m.pallmer@wtk-elektronik.de



## Appendices

### Appendix 1 – Overview of controller symbols

	Start key
	Access to the <b>MAIN MENU</b>
	Access to the <b>GRAIN SPACING</b> menu
	Access to the <b>WORK</b> menu
	Access to the <b>TEST</b> menu
	Access to the <b>DATA</b> menu
	Access to the <b>SET</b> menu
 	Folding frame key for release the folding frame control
 	
	ESC key: Exit working level
	Shift key for switching between the <b>MAIN MENU</b> and the application
	Enter key
 	Adjustment key for <b>grain spacing</b>
	Key: <b>Unit group change</b>
	Row marker key for selecting both row markers





Row marker key for selecting a row marker



Part width control key



Pre-dosing key



Tramline cycle pause key




Access to the **TRAMLINE** menu




Automatic tramline system key



Increase/decrease tramline cycle key




Reset preview key to 1<sup>st</sup> cycle



Field edge key



Access to the **SET** menu for setting the tramline parameters




Access to the **WORK MANUAL TL (row management)** menu



Unit ON/OFF key



General unit ON/OFF key



Mark out tramline key



Arrow key



Access to the **CONFIGURATION MENU**


















Motor test run key



# Operating manual Controller for precision seed drill



	Access to the <b>GRAIN SENSOR TEST</b> menu
	Interrupt motor test run key
	Cancel/end motor test run
	Delete key
	Delete section counter key
	Access to the <b>CONTRACT ACCOUNT</b> menu
 	Start and end key for work tasks
	Coordinate entry key for GPS function
	100m adjustment key
 	Start/finish key for 100m adjustment
	Access to <b>PERMANENT SHUTDOWN</b> menu
	Working position save key
	OFF switch



# Operating manual Controller for precision seed drill



## Appendix 2 – Quick start guide

Working cycle	Path
Switching device on/restarting software	 → 
Releasing folding frame control	 → 
Setting grain spacing	 →  →  / 
Switch row marker on/off	 →  →  / 
Part width control	 →  →  / 
Pre-metering	 →  → 
Tramline cycle: Pause	 →  →  / 
Setting tramline cycle	 →  →  →  / 
Setting edge of field	 →  →  →  / 
Setting the tramline parameters: cultivation width, track width, field edge, tyre width, minimum distance to the plant, mark out tramline, grain density, auxiliary manual tramline	 →  →  →  → 



# Operating manual Controller for precision seed drill



Switching units on and off	→ WORK →  →  →  →  →  →
Switching tramline marking out function on	→ WORK →  →
Perform motor test run	→ TEST →  →
Grain sensor test	→ TEST →
Recording working time and surface area worked	→ DATA
Separate customer data recording	→ DATA →
Setting sowing parameters: grain spacing, number of rows, row spacing, radar pulse, number of cells, grain alarm threshold, fertilisation wave monitoring working sensor and setting	→ SET
Entering coordinates for GPS function	→ SET →
100m adjustment for determining values for radar pulses	→ SET → 100m → START 100m → STOP 100m
Shutting units down permanently	→ SET →  →  →  →
Saving the working position threshold	→ SET →
Going back to the main menu	
Switching the device off	→