



DEMETER CLASSIC CS/CSA



Operating Instructions

Contents

Introduction	3	Tramline controls	15
Application	3	Tramline placement	15
General safety and accident prevention stipulations	3	Setting the distance between tramlines	17
Starting up	5	Maintenance	20
Gear and seed drill settings	6	D-01 Computer	21
Test sowing	10	Seedtable, CS/CSA 2500 (2,5 m)	30
Emptying the seed hopper	12	Seedtable, CS/CSA 3000 (3,0 m)	35
Setting coulter pressure	13	Seedtable, CS/CSA 4000 (4,0 m)	40
Tramline	14	Seedtable, CS/CSA 4500 (4,5 m)	45

Introduction



Before using the seed drill read these operating instructions carefully.

Make sure that all safety instructions are distributed to other users.

Note that the terms left, right, forward and backward used in these instructions refer to the seed drill seen in the direction of travel. Proper operation without accidents and long seed drill life can only be guaranteed if all instructions and safety precautions are closely followed.

Application

The Demeter Classic seed drill is designed exclusively for general agricultural applications. All other

purposes lie outside the scope of the machine and the manufacturer cannot be held liable for damage resulting from incorrect use. In such cases the user is entirely responsible for damage. Intended use is to be understood as operation in accordance with the information the manufacturer stipulates in operating, service and maintenance instructions.

The Demeter Classic seed drill may only be operated, serviced and maintained by persons who are conversant with the instructions, who are familiar with the machine, and who are aware of the dangers that can arise in using it.

The following accident prevention stipulations, normal safety rules, and health and traffic safety regulations must be observed unconditionally.

Unauthorised changes to the machine and its construction exempt the manufacturer from any form of responsibility or consequential damage and injury!

General safety and accident prevention stipulations

Before operating the seed drill and tractor, all traffic and operating safety measures must always be observed!

- In addition to the rules stated in these operating instructions, general safety rules and stipulations must be observed!
- The warnings and information labels give important information about reliable operation. Do not ignore them - they are there for your safety!
- Always observe current traffic regulations when driving on public highways!
- Before starting to operate the machine, make yourself familiar with the equipment and the operating elements and their function. It might be too late to do so when running!
- The tractor driver's clothes must be tight fitting. Loose clothes are an invitation to accidents!
- Before starting up, check to make sure that no one is near to the machine (especially children). Make sure you have good visibility!
- No persons other than the driver may be carried during operation or transport!
- Implements must be coupled correctly at the stipulated points!
- Remember to place supports when coupling or decoupling implements so that they do not tip up.
- Permissible axle loads, total weights and transport dimensions must not be exceeded!

- Transport equipment such as lights, warning signs and any protection devices must be checked and in position!
- Cables for releasing the three-point linkage quick coupling must hang loose so that they cannot release the coupling when the seed drill is lowered with the tractor lift.
- Never leave the cab while the tractor is moving!
- Driving, steering and braking characteristics can be affected by implements and weight. Make sure there is sufficient steering and braking capacity!
- The total length/width of tractor and implement must be taken into consideration when turning!
- The implement must only be operated when all protective devices are in working order!
- No persons other than the operator may be allowed in the working area!
- No person may be allowed in the turn and swing area!
- Hydraulically extendible parts may only be activated when no person is in the swing area!
- Remote controlled parts (e.g. hydraulic parts) present crushing and cutting hazards at certain points!
- Before leaving the tractor, lower the implement onto the ground, switch off the engine and remove the ignition key!
- No person may be allowed to stand between tractor and implement without the tractor being secured with the parking brake and/or chocks!
- Markers in transport position must be locked!

Built-on implements

- Before mounting or removing implements in the three-point linkage, control levers must be set so that unintentional raising or lowering cannot occur!
- When coupling to the three-point linkage, make sure that the coupling category of tractor and implement match each other!

- The three-point linkage area presents crushing and cutting hazards!
- Never stand between the three-point linkage and tractor or implement when operating the linkage!
- Check that the drawbars, etc. are secured against sideways movement when the implement is in its transport position!
- When driving on public highways with raised implement, the lift control lever must be secured against dropping!

The hydraulic system

- The hydraulic system is under high pressure!
- When connecting hydraulic cylinders the stipulations on connecting hoses must be observed!
- When hoses are connected to the tractor hydraulics, there must be no pressure on the tractor and implement hydraulics!
- When making hydraulic connections between tractor and implement the male and female couplings should be marked to prevent operating errors. If function connections are swapped (e.g. raise and lower functions are swapped over) the result could be dangerous!
- Hydraulic hoses should be regularly inspected and replaced if damaged, and before they become too old. New hoses must be of the same technical specification as stated by the original hose manufacturer.
- When looking for leaks, a suitable detection method is advisable to prevent damage!
- Escaping hydraulic fluid (oil) under pressure can penetrate the skin and cause severe injury! Such accidents can cause infection. Consult a doctor immediately!
- Before working on the hydraulics, lower the implement onto the ground. Release pressure from the system and stop the engine!

Tyres

- When working on the tyres, lower the implement onto the ground and use chocks to prevent rolling!

- Fitting tyres requires adequate knowledge and the correct tools!
- Repairs to tyres and wheels must only be carried out by authorised personnel using prescribed tools!
- Check tyre pressures regularly and ensure they are inflated to the prescribed pressure!

Maintenance

- Repair, maintenance, cleaning and inspection in relation to malfunction must only be carried out with the engine stopped!
- Under all circumstances, remove the ignition key!
- Nuts and screws must be inspected regularly and tightened if necessary!

- If maintenance work is carried out with the implement raised, it must always be well supported!
- When replacing sharp components, use the correct tools and wear gloves!
- Waste oil and grease must be disposed of in accordance with regulations!
- Always switch off electrical systems before working on them!
- When using electrical welding equipment on the tractor or implement, disconnect cables on generator and battery!
- Spare parts must be of the same specification as those stated by the manufacturer! Original spare parts meet this requirement!

Starting up

General

Seed drills are normally delivered ready for operation. However, for transport it can be necessary to supply some parts loose or not mounted in the actual working position.

- **Note! Do not lay loose parts down in the seed hopper as the agitation shaft might rotate and consequently be damaged when the machine is moved.**

Coupling the seed drill

The seed drill can be mounted either directly after the tractor or after a soil preparation implement, via the three-point linkage. The drawbar supplied is standard for category II. The bolt for the top link suits both category I and II. The top link must be

adjusted so that the seed drill stands vertically during sowing. The lift arms must have a certain amount of clearance so that the seed drill is able to line up with the tractor during sowing. When attaching the seed drill to a soil preparation implement equipped with connection hooks, account must be taken of the required clearance of 825 mm. The drawbars must be secured so that they cannot disengage in operation. Normally the top link must be set in its upper position.

Note! Make sure that the seed drill does not collide with the tractor when the tractor lift is raised.

Lights

When driving the seed drill on public highways all regulations in relation to the transport of agricultural equipment, including those governing lights, reflectors and warning signs, must be observed.

Markers - Transport position

When transporting the seed drill on public highways the markers must be pushed in and placed in their holders.

Filling the seed hopper

Before filling the seed hopper the seed drill must be coupled to the tractor or stand on firm ground, with support legs in place so that it cannot tip. Make sure that no foreign bodies, e.g. pieces of paper, enter the seed hopper as these can block the delivery tubes. When the seed drill lid is lifted, the level indicator ball automatically lifts. On closing the lid,

the ball comes down onto the seeds. Also make sure that the seed is distributed evenly in the hopper. If sowing takes place on slopes, the seed becomes displaced and causes the level indicator to give a false reading. Hopper dividers to prevent seed displacement can be supplied as extra equipment.

Note! If the seed hopper is to be filled with seed from sacks, the easiest method is to lay the sack above the open lid rather than down into the hopper.


Note! Do not place your hands down into the seed hopper when the agitation shaft is rotating!

Gear and seed drill settings

Gears

The gearing can be changed infinitely by loosening the adjustment handle with the cross key. The settings on the scale correspond to those in the sowing table. The higher the scale reading, the larger the seed rate.

Note! The cross key must be tightened firmly so that the gearing cannot adjust itself.




Combi seed rollers

Full seed roller:

This setting, where both roller halves are coupled in, is used for all types of grain and large seeds.

Fine seed roller:

This setting, where the righthand sowing roller half only is coupled in, is used for fine seeds.




Coupling in and out seed roller halves:

Moving the changeover cam outwards uncouples the seed roller halves. These are then pressed against the seed hopper so that they cannot rotate.

Bottom flaps

To ensure gentle seed delivery, spring-loaded adjustable bottom flaps are placed under the combi seed roller. The adjusting lever (fig. 3) can be set in six different positions:

- 1st groove, e.g. rape
- 2nd groove, e.g. wheat
- 3rd groove, e.g. spelt
- 4th groove, e.g. lupines
- 5th groove, e.g. peas
- 6th groove, e.g. beans



Note!


With large seeds (e.g. peas, beans) and depending on their size, grooves 5 or 6 are suitable. Quantity adjustments must not be made with the bottom flap lever because open flaps will result in irregular sowing while closed flaps might result in damaged seeds.

Setting the bottom flaps

a: Check bottom flap pretension:


- On about three bottom flaps, measure the clearance with slide callipers (fig. 4) through the emptying flaps. (When taking the measurement the bottom flap lever must be in position 3).

- With correct pretension the measurement must be 8.5 mm (fig. 4).



b: Setting of bottom flap clearance:

- Using an 8 mm socket spanner (fig. 5) to set the clearance as required (fig. 4).
- When correcting the settings of the three bottom flaps chosen, note the average number of spanner turns required to produce the necessary pretension in these bottom flaps.
- All bottom flaps can then be adjusted (without further measurement) by turning the spanner the average number of times.




c: Checking the bottom flap setting:

- The bottom flap lever must be activated until slight resistance is met (excess force must not be used). In this position the setting element must be opposite the lever pointer for the bottom flaps (see fig. 6). If a variation occurs it must be corrected.

d: Setting the setting element:



- Loosen the screws in the setting element (fig. 6) and adjust to the correct position. Retighten the screws after adjustment.



e: Fine adjustment of seed roller bottom flap:

- Using the adjustment gauge "E" (optional equipment) the bottom flap must be set precisely in relation to the seed roller.
- Set the lever for the bottom flaps in pos. 2 (fig. 3). Now guide the gauge between the row of the seed roller studs and seed hopper and push down towards the bottom flaps (figs. 7). Do not use excess force.

- The notched edge "K" must lie close to the upper edge of the feed box (figs. 8).
- Adjustments can be made with the setting screw (fig. 5). Turning the screw clockwise increases the distance between bottom flaps and seed roller, i.e. the gauge moves to a position below feed box edge "G". Turning the screw counterclockwise reduces the distance and the gauge moves to a position above the feed box edge "G".



Seed shutter

The seed shutter can be moved in four stages to regulate the quantity of seed in the feed box (fig. 10).

Position „0“ - to cut out a single row



Position „1“ - for fine seed, e.g. rape

Position „2“ - for all grain and other large seeds

Position „3“ - for light seed with much chaff, e.g. grass

Warning:

The seed shutter must never be placed in an intermediate position as this will damage the spring action created by the groove positions.




Agitation shaft

With fine seed the agitation shaft must be uncoupled. Remove the split pin from the chainwheel (fig. 11) and place in the marker fitting.

Note! The split pin must only be fitted as shown.

With very light types of grass seed it can be necessary to use a special agitation shaft for grass seed (extra equipment).






Test sowing

A test sowing can be conducted to check the quantity of seed necessary.

- Adjust gear, bottom flaps, seed shutter and seed roller as described.
- Half fill the seed hopper with seed.
- Fold down the emptying trough (fig. 13).
- Open the emptying flaps (fig. 14).
- Turn the gear crank (fig. 15) about 30 times and tip discharged seed back into the seed hopper.
- Turn the crank the necessary number of times (according to the table), depending on the working width and tyres (fig. 12).

Fig. 12 Calibration of the level						
Tyred wheel						
m	5.00-15		6.00-16		10.00-15	
	Land wheel		Land wheel			
	ha	1/40 ha	ha	1/40 ha	ha	1/40 ha
2,50	5091	127	4378	109,5		
3,00	4242	106	3648	91	3394	85
4,00			2736	68,5	2815	70,4
4,50			2432	61	2467	62

The table gives the number of turns for 1 hectare and 1/40 hectare (e.g. 3648/91). The first figure is for 1 hectare, the second for 1/40 hectare. As a rule 1/40 hectare is sown and the weight of seed is multiplied by 40. With smaller sowing quantities (rape) it is recommended that 1/10 be used to avoid weighing errors. Test sowing must not be run with



uncoupled seed roller for tramlines. If variations from the desired value occur, the gearing must be adjusted and the test run again. When the desired value is achieved, a further test is necessary to check the seed rate.

- Close emptying flaps (fig. 16).
- Fold up the emptying trough and secure it.

Example:

Machine working width: 3,0 m
 Number of rows: 25
 Tyres: 6.00-16
 Desired quantity: 200 kg/ha
 Seed: Wheat

Setting from the sowing table:

Bottom flap: 2nd groove
 Seed shutter: 2nd groove
 Seed roller: Full
 Gear setting: 60
 RPM for 1/40 ha: 91

Seed quantity in emptying

trough: 4,5 kg x 40 = 180 kg

Gear setting increased to: 66

Seed quantity in emptying

trough: 5,0 kg x 40=200 kg/ha

The jolt that might occur during test sowing comes from the transmission coupling engagement and is not a machine fault.

Warning:

The sowing table gives approximate values and is therefore indicative only because each seed type is different in size, condition and density from year to year. In addition, the flow characteristics of dressed seed differ. See also "Sowing control" below. When spacing with two closed rows per tramline the seed rate is reduced in relation to the sowing table values by up to approx. 7%, depending on the tractor tramlines.

Sowing control

The test sowing simulates general field sowing where unforeseen circumstances can affect the seed rate.

In stated lever positions and wheel speeds/ha, account has been taken of a certain amount of wheel slip. In practice there can also be considerable deviation, in spite of the large wheels. If liquid seed dressing is used, flow characteristics during sowing can be different over time. After sowing 500 m, operational values will become more or less constant.

Especially when combinations of soil cultivation implements are used, strong vibrations may affect

the seed drill. As a rule, these increase the seed rate.

If one or several of the above factors occur, trial sowing should be repeated after 500 m. The most accurate control can be achieved by a short trial, i.e. for 100 m drive with at the usual speed and by opening the bottom flaps allow the seed to be caught in the emptying trough. Depending on the working width, the collected quantity must be multiplied by:



- 2,5 m working width x 40,0
- 3,0 m working width x 33,3
- 4,0 m working width x 25,0
- 4,5 m working width x 22,22

Emptying the seed hopper

To empty the seed hopper, fold down the emptying trough (fig. 17). Open the emptying flaps (fig. 18) with the key (fig. 19). If necessary, open all seed shutters (fig. 20). Fully open the bottom flaps by positioning the setting lever (fig. 21) fully forward so that remaining seed is able to run down into the emptying trough.

When the emptying trough is full, the bottom flap lever must be closed again and the emptying trough similarly emptied.

If the machine is to be stored for a long period it must always be empty. Clean the bottom flaps and leave them fully open. Failure to do this encourages mice to try entering the seed hopper by gnawing their way through the flaps and seed roller.



Setting coulter pressure

Generally the coulter pressure determines the sowing depth. That is why implements are designed to ensure that the pressure is as uniform as possible across the entire swing area.


Central setting of coulter pressure

Coulter pressure can be set via the spindle, using the pressure adjustment crank (fig. 22 + 23).

Turning the crank clockwise increases the pressure and turning it counterclockwise reduces the pressure. When marking, the spindle and thereby also the pressure can be read off.

Setting individual coulter pressure

Individual coulter pressure can be set using the springs (fig. 24 + 25).



Tramline

Pitch	Seed drill working width	Spraying width	Symmetrical tramline placement in one pass Asymmetrical tramline placement in two passes
3	2.50 m 3.00 m 4.00 m	7.50 m 9.00 m 12.00 m	
4	2.50 m 3.00 m 4.00 m	10.00 m 12.00 m 16.00 m	$1/2$
5	2.50 m 3.00 m 4.00 m	12.50 m 15.00 m 20.00 m	
6	2.50 m 3.00 m	15.00 m 18.00 m	$1/2$
7	2.50 m 3.00 m	17.50 m 21.00 m	
8	2.50 m 3.00 m	20.00 m 24.00 m	$1/2$
$\frac{3}{4}$	2.50 m 3.00 m 4.00 m	10.00 m 12.00 m 16.00 m	
$\frac{5}{6}$	2.50 m 3.00 m 4.00 m	15.00 m 18.00 m 24.00 m	
$\frac{7}{8}$	2.50 m 3.00 m	20.00 m 24.00 m	

Tramline controls

These controls can be used to determine tramline placement so that seeding does not occur in the tramlines where the tractor will subsequently run during fertiliser spreading, spraying, etc. The distance between tramlines will depend on the working width of the seed drill and following implements such as fertiliser spreaders and sprayers. Normally, when the required distance between tramlines has been determined, two seed rollers per row are closed - in some circumstances three or more. The tramline distance will depend on the wheel base of the tractor used for fertiliser spreading and spraying.

Tramline placement

Different types of tramlines

Symmetrical tramlines (fig. 26)

With symmetrical tramlines the two are placed in a single pass with the seed drill.




Fig. 26

Asymmetrical tramlines (fig. 27)

With asymmetrical tramlines one tramline is placed in each of two successive passes with the seed drill.




Fig. 27

drill. The disadvantage with this method is that if the seed drill is not driven precisely, on slopes for example, tramline placement will not be correct.

Selecting the tramline type

Symmetrical tramlines (fig. 28)

In most cases symmetrical tramlines are preferable. When odd-number pitches are used, e.g. 3/5/7/9, only symmetrical tramlines can be used (fig. 28).

(Pitch = spraying width divided by seed drill width
E.g. $12:4=3$)

With even-number pitches, e.g. 4/6/8, asymmetrical tramlines can also be used (fig. 27)




Fig. 28

If symmetrical tramlines are used with even-number pitches 4/6/8, the seed drill width and spraying width do not match at the start of the field. Depending on where the first tramlines are placed, either overlapping or an unsprayed section will appear at the start of the field.

There are two ways of solving this problem:

a) Placement of tramlines in one pass using pitches 4/6/8.

When using seed drills of smaller working width, tramlines can be placed in the first pass. However, for spraying, half the boom must be shut off.

b) Uncoupling half the seed drill width (fig. 29).

Another possibility is to shut off half the machine's seed shutter so that only half the working width is used on the first pass.

Remember to open the closed seed shutter before the next pass with the seed drill.

For the next pass with the seed drill the machine cannot be driven using the marked tramline. Instead, the centreline of the tractor must be on the edge of the first tramline. There will normally be a difference in colour between worked and unworked

soil, which makes it easier to follow the edge of the first tramline.

Asymmetrical tramlines (fig. 30)

Asymmetrical tramlines can only be used with pitches 4, 6 and 8.

With asymmetrical tramlines, the full width of the seed drill can be used already on the first pass since the seed drill and spraying widths can be matched without meeting the problems described in "Selecting the tramline type". Since asymmetrical tramlines must be placed in two successive passes, on which side of the seed drill the seed rollers are to be shut off must be selected. This means that a decision has to be made whether to sow from the right to left or vice versa.




Fig. 29




Fig. 30

Setting the distance between tramlines

Symmetrical tramlines

The distance between tramlines must correspond to the wheel base of the tractor used for spraying and fertiliser spreading.

The tramlines must be placed by the seed coulters on each end of the seed drill. These are located at half wheel base from the centreline of the machine. When supplied by the factory, the wheel base is normally 1.5 m. If this distance does not suit the

tractor used for spraying and fertiliser spreading, the seed drill must be modified as described below.

Asymmetrical tramlines

First, the seed coulters to be used to place the tramlines must be selected:

From the outer seed coulters on righthand or left-hand side (depending on the chosen sowing direction) place a measuring tape so that its end is half a row pitch outside the coulters, e.g. 3 metre working width divided by 25 seed rollers = 6 cm. Then measure a half wheel base, e.g. 0.75 m in towards the seed drill centre. The tramlines must be placed by the two coulters nearest the measured point.

Changing the distance between tramlines

- Decide which seed roller best matches the required distance between tramlines.
- Turn the seed shaft with the crank so that the keyway is visible (fig. 31).
- Loosen the clamping bands that secure the gearwheels to the countershaft so that they can be slid sideways (fig. 32).
- Pull the countershaft back and slide the gearwheels to the new position (fig. 33).




Fig. 31




Fig. 32




Fig. 33

If a bearing plate is installed by the selected seed rollers, it must be moved to the neighbouring roller as follows:

- Remove all springs holding the bearing plates in position.
- Pull the countershaft back and turn the bearing plate free of the hexagonal spindle.

Note! Turn the hexagonal spindle with the handle for the emptying shutters so that the hexagon bar lines up with the cut-outs in the bearing plate (fig. 34).




Fig. 34

- Move the bearing plate to the new position and turn it back on the hexagonal spindle. Now refit the springs to hold the bearing plate in position.
- Remove the two gearwheel halves from the seed roller (fig. 35).




Fig. 35

- Using a pointed tool, extract the key from the selected seed roller (fig. 36).




Fig. 36

- Fit the key in the seed roller where the drive is mounted (it should click when engaging).
- Fit the two gearwheel halves on the selected seed roller: Press the one half securely onto the seed roller from above.

Note! The spigots on the gearwheel halves mate with the round recesses on the seed roller coupling side.

- Turn the seed roller 180° so that the first half turns in towards the feed box bearing.
- Now fit the other half and fasten the two halves together using the two screws.
- Finally, check to make sure that the gearwheels on the countershaft line up with the gearwheel halves and that the gearwheels are firmly secured.

Changing over the seed drill from symmetrical to asymmetrical tramlines


The seed rollers which are not to be used must be uncoupled from the drive.

Loosen the clamping band that secures the gearwheel on the countershaft (fig. 37)

Extract the key with a screwdriver

Slide the gearwheel along the countershaft and retighten it.

The key removed from the countershaft must be fitted in the seed roller gearwheel, fig. 38 (a click will be heard when it engages).




With electronic tramline control, similar adjustments must be made.

Setting up a third row

The width of the tramlines is determined by the row pitch and the number of seed rollers that are stopped. When a track width wider than can be achieved with two seed rollers is required, a third row can be set up.


Extract the key from the selected seed roller with a screwdriver.

Fit the two gearwheel halves on the side of the seed roller. Slide the extra gearwheels to the required position along the countershaft and secure them with clamping bands and the key removed from the seed roller.



Checking

During operation, the function of the equipment used in tramline placement can be checked using a vertical scale on the front of the seed hopper. When tramlines are placed (seed rollers do not turn round) the indicator remains stationary. The numbers on the scale give a more accurate reading of the seed rate when the needle moves very slowly, as when sowing rape seed for example.



Maintenance

The life and reliability of the seed drill depend on good maintenance. Therefore the following points must be observed. See also section "Maintenance" in the general safety and accident prevention instructions.

Gearbox

The infinite oil-bath gearbox is filled with oil at the factory. The sight glass can be used to verify the oil level. The quantity of oil is correct when the level is halfway up the sight glass. Oil change is not necessary, but to replenish the oil check with the table on page 21. The total quantity of oil in the gearbox is 1 litre.

Driving wheels

See also "Tyres" in the general safety and accident prevention instructions. Check the air pressure in the driving wheel tyres regularly. The correct pressure is 2.5 bar.

Chain drives

Chain drives must be retensioned after the first 10 hours of operation and then once each year. Clean and grease chains after each season.

Sowing coulters

The sowing coulters need no maintenance. If they become loose, retighten the hexagon screws, M10 x 90. With safety coulters the tips should be checked once each year and replaced as necessary. Only in this way can the correct placing of seeds be guaranteed.

- The disc coulters have double ball bearings which are supplied lubricated for life. The scrapers, must be replaced when they become worn.

Depth wheels

The depth wheels must be lubricated daily. When the machine is stored after a season, make sure that the depth wheels are not under load.

Markers

Marker discs are fitted with double ball bearings and must be lubricated weekly. The mechanical tramline control must be lubricated every day.

Plastic parts

These parts must be cleaned after each season, but not with cleaning agents containing solvents or thinners, nor with petrol, diesel fuel or waste oil.

Hydraulic hoses

See also "The hydraulic system" in the general safety and accident prevention instructions. Retighten screwed connections after the first 10 hours of operation. At the start of each season, check the hoses and replace them when necessary.

Monitor

Even though the monitor is located close to the water spray, it must not be subjected to direct rainfall. A dry place is recommended for after-season storage.


Cleaning the seed hopper

After the season the seed hopper must be completely emptied and thoroughly cleaned. It must be stored with bottom flaps and seed shutter fully open. Seed residue in the seed hopper encourages mice to try entering the seed hopper by gnawing their way through the flaps and seed roller.

Gearbox oil

ARAL	ARAL OEL DEGOL BG 46
BP	BP Energol GR-XP 46
CHEVRON	CHEVRON ATF CHEVRON EP industrial 46
ESSO	NUTO H 46
MOBIL	MOBIL DTE 25
SHELL	DONAX TM
TEXACO	RANDO OIL HD B 46

D-01 COMPUTER



Contents

General Information	22	Implement working width	27
System description	23	Tram line function	27
Technical specification	23	Tramline programming	27
D-01 computer description	24	Area and area total counters	28
D-01 computer operation	24	Area counters- Reset function	28
Start-up test	25	Speedometers	28
Entry of implement parameters	25	Pause function	28
Entry of implement wheel circumference	26	Implement computer	29
Entry of wheel circumference.		The functioning of the implement	
The practical method..	26	computer	29

General Information

D-01 controller is a computer system used for control and measurement on drills and other agriculture machines. The main function of D-01 controller is tram line marking and monitoring. Moreover it en-

ables the measurement of working speed, area, and area total. Owing to the surface mounted device technology, the modules of the controller are compact and reliable.




Fig. 1 Modules of D-01 controller

System description

D-01 system consists of the following modules (Fig. 1)

1. **D-01 control computer** with a keyboard and a display
2. **Implement computer**. This module connects the D-01 control computer with sensors, an actuator and a solenoid.
3. **External control cable**. It connects the D-01 computer with the implement computer.
4. **Internal control cable**. It connects the D-01 computer with a socket.
5. **Wheel sensor**. The wheel sensor sends electric impulses to the implement box when it detects wheel rotations. It interacts with a magnet placed on a rotating part of a machine (or the wheel itself). The rotating part must be synchronised with wheel rotations.
6. **Implement sensor**. It detects a moment when a machine is lifted (lowered). It interacts with a magnet which is placed on a moving part of the machine.
7. **Solenoid**. It switches on/off the tramline markers.
8. **Actuator**. It lifts/lowers the pre-emergence markers.
9. **Main plug**. It is connected with the socket.
10. **Internal power supply cable 12V** which is connected to an accumulator and the socket.
11. **Fuse 20A**
12. **Contact terminal** for 12V accumulator (+)
13. **Contact terminal** for 12V accumulator (-)

All sensors and control components (5..8) are equipped with cables for connection with the implement computer.

Technical specification

- Resolution of speed measurement – [km/h] 0.1 km/h
- Resolution of hectar per hour measurement - [ha/h] 0,01 ha/h
- Resolution of the area counter [ha/h] 0,1 ha/h
- Resolution of the area total counter 0,1/1 ha
- The spacing between tramlines 2-9 spor
- Double (symmetrical) tramline function
- Automatic electronic storage of all counters in case of power shutdown
- The durability of counter and parameter memory > 10 years
- Optical signalling of function settings
- 4 digit illuminated liquid crystal display
- Pressed-key and special device modes acoustic signalling
- The maximum work time of the pre-emergence actuator (one way direction movement). 15 seconds
- The power saving mode of the implement computer
- The time delay of the power saving mode activation 25 seconds
- The power load of the implement computer in the power saving mode < 20 mA
- The diagnostic lamp in the implement computer for simple and easy testing of the control and implement computers
- Acoustic signalling when there is no data transmission between the control and implement computers

D-01 computer description

D-01 computer:

- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Illuminated liquid crystal display 2. Control cable socket 3. Screw sockets for control cable plug | <ol style="list-style-type: none"> 4 - 14. Function keys and lamps that indicate the selected function 15. - 19. Setting and control keys, the PAUSE function lamp 20. Power on/off switch |
|---|---|




Fig. 2 Keyboard and display of D-01

D-01 computer operation

The user of D-01 can perform the following actions:

- | | |
|--|--|
| <ol style="list-style-type: none"> 1. The programming of: <ul style="list-style-type: none"> • Implement wheel circumference • Implement working width • Single or double tram lines 2. The read-out of: <ul style="list-style-type: none"> • Working speed km/h | <ul style="list-style-type: none"> • Working speed ha/h • Area • Area total • Track number <ol style="list-style-type: none"> 3. The blocking of sensor signals 4. The manual correction of the current track number |
|--|--|

The function keys are used for parameter/function selection. The parameter/function value is shown on the display. The selected parameter/function is indicated by the corresponding lamp. The selection of one of two parameters/functions related to keys 4, 7, 10 can be done by repeated pressing of the same function key.

The selected parameter can be changed in the programming mode. To enter the programming mode you must press and hold key 19 (approx. 3 seconds) until the long sound is heard. In the programming mode, it is possible to change selected parameters (keys 4, 13) and zero the area counters (key 10). The area counters can be zeroed by pressing key 15.

The setting of parameters is a little bit more complicated. To select one of the four digits on the display that we want to modify, we must use key 18 (the

selected digit starts to flash). Key 17 is used to change the chosen digit value in the range 0..9

In the tramline programming mode, only one digit is active. Key 18 is used for setting/resetting of tramlines in the range 2..9

To exit the programming mode you must press key 19 (STORE). The modified parameter is stored in the memory.

When you press key 15 (PAUSE) during a normal operation of the computer the red lamp 16 will be switched on. In this mode the wheel and implement sensors are disconnected from the computer.

The intermittent acoustic signal generated by D-01 computer is an alarm that there is no connection with the implement computer.

Start-up test

When the power supply is connected to the controller, the computer should work in the following way:

The long acoustic signal, all the display segments and control lamps are switched on.

The control lamps are switched off. The display should show "D-01"

The "D-01" notice is deleted and the computer enters the tramline function, the display shows the current track number.

IMPORTANT!

If any failure is observed during the test, we recommend to switch off and switch on the power

supply. If the failure persists we recommend to contact your dealer

Entry of implement parameters

In order to ensure the correct measurement of speed and area, you must make encodements of wheel circumference and working width before putting your agriculture machine into use. The encoded parameters are stored in the non-volatile memory of the computer. This memory does not require power supply. The stored parameters are retrieved from the memory every time the computer is switched on.

You must take care of proper setting of implement parameters, otherwise the area/speed measurement will be incorrect.

Entry of implement wheel circumference

- Press key 4 until the lamp next to the wheel sign is switched on.
- The display will show the previously set value of wheel circumference in centimeters.
- Enter the programming mode using key 19
- Select the digit that you want to modify using the arrow key 18. The active digit is flashing.
- Using the arrow key 17 set the required value of the selected digit.

- If it is needed return to the step 4
- When the required wheel circumference is selected, press key 19 to store this value and exit the programming mode.

The wheel sensor magnet on CS drills is mounted on a moving part that rotates faster than the wheel itself (the ratio of rotations is 28:11). To ensure the correct area and speed measurement the wheel circumference encodement must be made according to the following formula:

$$\text{Wheel circumference} = \text{real wheel circumference} \times 0,393 \quad (11/28=0,393)$$

Wheel specifications for DK drills:

Type of wheel	Real circumference [cm]	wheel circumference [cm]
6,00-16	229	90
10,00-15	239	94

Entry of wheel circumference. The practical method.

This method is an alternative to the one from the previous section. It is independent of the machine type and tyres. To apply this method you need to mark a trial distance.

1. Mark the trial distance in the field for example: 100m.
2. As a working width enter the number 1000 into the D-01 computer.
3. As a wheel circumference enter the number 1000 into the computer.
4. Reset the area counter [ha], keep the read-out of area counter active.
5. Drive the machine along the trial distance.
6. After you have driven the trial distance read the area counter.
7. Use the following formula to calculate the wheel circumference:

Wheel circumference

$$\text{in centimeters} = \frac{\text{Trial distance in meters}}{\text{Area counter value [ha]}}$$

8. Enter the calculated wheel circumference into the computer.
9. Enter the real working width into the computer.
10. The D-01 controller is configured and ready to work.

Example

The trial distance is 100 meters.
After the trial distance has been driven, read the area counter.
The area counter value is 1.04.

The data obtained enter into the formula in step 7.

$$\text{Wheel circumference [cm]} = \frac{100 \text{ m}}{1,04} = 96,2$$

Enter the number **96** into the computer.

Implement working width

1. Press the key 4 until the lamp next to the working width sign is switched on.
2. The display will show the previously set value of working width in centimeters.
3. Enter the programming mode using key 19
4. Select the digit that you want to modify using the arrow key 18. The active digit is flashing
5. Using the arrow key 17 set the required value of the selected digit
6. If it is needed return to step 4
7. When the required working width is selected, press key 19 to store this value and exit the programming mode.

IMPORTANT!

The wheel circumference and working width parameters are entered in centimeters.

Tram line function

- *Press key 14 to select the tramline function*
The display shows the current (one-digit) track number. If the digit flashes, it means that the current track is a tramline.

The controller D-01, when programmed, can be used for automatic tramlining. The distance between tramlines can be selected from the interval 2..9. It is also possible to make double tramlines for example: 2&3, 3&4 etc.

While tramlining the computer controls the solenoid (10 fig. 1) which selectively suppresses seeding. If you have the D-01 kit with rear tramline actuator the rear tramlines can also be made automatically. The track number is incremented automatically when the machine is lifted. This is possible due to the implement sensor (9 fig. 1). If the sensor detects the lifting of the machine, the computer makes the short sound. Any false impulses from the sensor are eliminated by the computer.

Note: In order to test the implement sensor manually you must keep a magnet near the sensor for at least 3 seconds. If you want to make the next impulse keep magnet away from the sensor for at least 10 seconds and move it closer again.

When PAUSE function is activated the automatic tramlining is disabled.

When tramling function is on (the lamp 14 is switched on) you can manually change the current track using the arrow key 17.

The current track/tramline setting is stored in the non-volatile memory.

Tramline programming

1. Select the tramline function (key 13). Lamp 14 will be switched on.
2. The display will show the current track number.
3. Enter the programming mode by pressing key 19. This is confirmed by a long sound and the red lamp 16.
4. Using the arrow key 17 select the track number that you want clear or set a tramline.
When the track digit flashes it means this track is programmed as a tramline.

NOTE: It is easy to notice, that D-01 computer prompts the user to enter only the proper tracks. It is possible to program only a single track (from the range 2..9) or two tracks close to each other (double tracks, for instance: 2,3; 4,5 etc.).

For example: If the programmed track is 5 the computer permits you to select tracks: 4,5,6. If you want to set track 7 as a tramline you should clear the track 5 first. Otherwise the computer will not allow you to select the track 7.

5. Using the arrow key 18 clear or set the selected track as a tramline.
6. If it is needed return to the step 4
7. When you have finished, store the selected tracks and exit the programming mode (press key 19).

Area and area total counters

Press key 10 to select the required function. The lamp 11 will be turned on if you have selected function [ha] (area counter) or the lamp 12 will be switched on if the selected function is area total counter [ha+]. The display will show the selected counter value.

The D-01 controller can measure the worked in area and area total counters. The result of area calculation depends on the number of impulses from the wheel sensor, the programmed working width and wheel circumference.

The counters work simultaneously and independently. They differ only in capacity and resolution (see section 3). They can be cleared individually however the initial state of the counters cannot be set. When the PAUSE function is active the counters are stopped.

NOTE:

Ha -area counter in hectares (for example: the worked area during one day or week).

Ha + -area total counter (for example: the worked area during one month or year).

Area counters- Reset function

1. Using key 10 select the area counter that you would like to clear.
2. The display will show you the value of the selected counter.
3. Enter the programming mode by pressing key 19. The programming mode is confirmed by a long sound. Simultaneously the selected counter value starts flashing.
4. To exit the programming mode without clearing the counter press key 19. To clear the counter press key 15 (CLEAR).

Speedometers

- *Press key 7 to select the kilometer per hour [km/h] meter or the hectare per hour [ha/h] meter. The display will show the current status of the selected meter.*

The speed measurement is based on the frequency of impulses from the wheel sensor and on the programmed values of working width and wheel circumference.

If the wheel sensor does not send any impulses for more than 10 seconds the machine has stopped. The speedometers are zeroed.

The speedometers do not work if the PAUSE function is enabled.

Pause function

Press key 15 if you want to hold the signals from the sensors (the red lamp switches on). When you press the key again the function is deactivated and the red lamp is switched off.

IMPORTANT!

The activation of PAUSE function:

- Stops the area counters
- Disables the automatic incrementing of the current track number

When PAUSE function is activated (lamp 14 is switched on) you can manually change the current track using the arrow key 17.

Implement computer

The inside of the implement computer is shown in Figure 3.




Figure 3. The inside of the implement computer.

- | | |
|---|---------------------------------------|
| 1. Connector of the external control cable (3-wire cable) | 4. Solenoid connector |
| 2. Wheel sensor connector | 5. Pre-emergence actuator connector |
| 3. Implement sensor connector | 6. Implement computer diagnostic lamp |
| | 7. Cable fasteners |

The functioning of the implement computer

The implement computer has the diagnostic lamp 'LINK' which can be used to test the whole D-01 system. When the D-01 system is working properly the diagnostic lamp can be in one of the two modes:

1. Slow flashing (around 5 times a second). It means that the D-01 control computer is not communicating with the implement computer. The control computer is either disconnected from the implement computer or is switched off.
2. Very fast flashing. It means that the D-01 control computer and the implement computer are connected with each other and are working properly.

(PLEASE NOTE! This is the working state of the D-01 system)

If the diagnostic lamp is constantly turned on or off it means there is no power supply in the implement computer or the implement computer is damaged.

If there is no connection between the control and implement computer and the machine is not moving for more than 25 seconds the implement computer enables the power saving mode. In the power saving mode the solenoid is turned off to save the power of the accumulator (it is the situation when the solenoid was already working; for example when the D-01 system was tramlining). The power saving mode is cancelled when the communication between the control and implement computer is re-established.

Seedtable DEMETER CLASSIC CS/CSA 2500 (2,5 m)

Type	Tyred wheel	Calibration of the level			
		1 Ha	1/4 Ha	1/10 Ha	1/40 Ha
CS	5.00 - 15	5091	1273	509,1	127,3
	6.00 - 16	4378	1095	437,8	109,5
CS-A	Land wheel	4378	1095	437,8	109,5

Demeter Classic CS/CSA 2500 (2,5 m)

Wheat, L.weight 880 g/l, TSW 48 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel										
6.00	1	17	19	21	23	25				
-16										
15	2,54	43	48	53	58	64				
18	3,17	54	60	67	73	79				
21	3,48	59	66	73	80	87				
24	3,88	66	74	81	89	97				
27	4,38	74	83	92	101	109				
30	4,82	82	92	101	111	121				
33	5,28	90	100	111	121	132				
36	5,77	98	110	121	133	144				
39	6,22	106	118	131	143	156				
42	6,75	115	128	142	155	169				
45	7,21	123	137	151	166	180				
48	7,73	131	147	162	178	193				
51	8,27	141	157	174	190	207				
54	8,76	149	166	184	201	219				
57	9,46	161	180	199	217	236				
60	9,77	166	186	205	225	244				
63	10,37	176	197	218	238	259				
66	10,95	186	208	230	252	274				
69	11,48	195	218	241	264	287				
72	12,06	205	229	250	277	302				
75	12,44	212	236	261	286	311				
78	13,28	226	252	279	305	332				
81	13,91	236	264	292	320	348				
84	14,12	245	274	300	332	360				
87	15,15	258	288	318	349	379				
90	15,55	264	296	327	358	389				
93	16,12	279	312	345	378	410				
96	16,89	287	321	355	388	422				
99	17,64	300	335	370	406	441				
102	18,47	314	351	388	425	462				

Demeter Classic CS/CSA 2500 (2,5 m)

Barley, L.weight 797 g/l, TSW 52 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel										
6.00	1	17	19	21	23	25				
-16										
15	2,08	35	40	44	48	52				
18	2,59	44	49	54	60	65				
21	2,85	48	54	60	65	71				
24	3,17	54	60	67	73	79				
27	3,58	61	68	75	82	90				
30	3,95	67	75	83	91	99				
33	4,32	73	82	91	99	108				
36	4,72	80	90	99	109	118				
39	5,09	87	97	107	117	127				
42	5,53	94	105	116	127	138				
45	5,90	100	112	124	136	147				
48	6,32	108	120	133	145	158				
51	6,77	115	129	142	156	169				
54	7,17	122	136	151	165	179				
57	7,74	132	147	163	178	194				
60	8,00	136	152	168	184	200				
63	8,49	144	161	178	195	212				
66	8,96	152	170	188	206	224				
69	9,39	160	178	197	216	235				
72	9,87	168	188	207	227	247				
75	10,18	173	194	214	234	255				
78	10,87	185	207	228	250	272				
81	11,38	194	216	239	262	285				
84	11,80	201	224	248	271	295				
87	12,40	211	236	260	285	310				
90	12,73	216	242	267	293	318				
93	13,44	228	255	282	309	336				
96	13,82	235	263	290	318	346				
99	14,44	245	274	303	332	361				
102	15,12	257	287	317	348	378				

Demeter Classic CS/CSA 2500 (2,5 m)

Oats, L.weight 552 g/l, TSW 38 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha					
	Number of rows					
Tyred wheel						
6.00	5.00	1	17	19	21	23
-16	-15					25
63	57	5,95	101	113	125	137
66	60	6,28	107	119	132	145
69	63	6,59	112	125	138	152
72	65	6,92	118	132	145	159
75	68	7,14	121	136	150	164
78	71	7,62	130	145	160	175
81	73	7,98	136	152	168	184
84	76	8,28	141	157	174	190
87	79	8,70	148	165	183	200
90	82	8,93	152	170	188	205
93	84	9,42	160	179	198	217
96	87	9,69	165	184	204	223
99	90	10,13	172	192	213	233
102	92	10,60	180	201	223	244
105	94	10,95	186	208	230	252
108	97	11,31	192	215	238	260
111	99	11,70	199	222	246	269
114	102	12,34	210	234	259	284
117	105	12,57	214	239	264	289
120	109	13,05	222	248	274	300
123	112	13,57	231	258	285	312
126	114	14,14	240	269	297	325
129	117	14,44	245	274	303	332
132	120	15,08	256	287	317	347
135	123	15,42	262	299	324	355
138	126	16,16	275	307	339	372
141	129	16,55	281	314	348	381
144	132	16,96	288	322	356	390
147	134	17,63	300	335	370	405
150	137	18,00	306	342	378	414
						450

Demeter Classic CS/CSA 2500 (2,5 m)

Rye, L.weight 775 g/l, TSW 40 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha					
	Number of rows					
Tyred wheel						
6.00	5.00	1	17	19	21	23
-16	-15					25
15	14	2,10	36	40	44	48
18	18	2,62	44	50	55	60
21	20	2,87	49	55	60	66
24	22	3,20	54	61	67	74
27	25	3,62	61	69	76	83
30	27	3,98	68	76	84	92
33	30	4,36	74	83	92	100
36	33	4,76	81	90	100	110
39	35	5,14	87	98	108	118
42	38	5,58	95	106	117	128
45	41	5,95	101	113	125	137
48	44	6,38	108	121	134	147
51	45	6,83	116	130	143	157
54	48	7,23	123	137	152	166
57	52	7,81	133	148	164	180
60	54	8,07	137	153	169	186
63	57	8,56	146	163	180	197
66	60	9,04	154	172	190	208
69	63	9,48	161	180	199	218
72	65	9,96	169	189	209	229
75	68	10,28	175	195	216	236
78	71	10,97	186	208	230	252
81	73	11,49	195	218	241	264
84	76	11,91	202	226	250	274
87	79	12,52	213	238	263	288
90	82	12,85	218	244	270	295
93	84	13,56	231	258	285	312
96	87	13,95	237	265	293	321
99	90	14,57	248	277	306	335
102	92	15,25	259	290	320	351
						381

Demeter Classic CS/CSA 2500 (2,5 m)

Peas, L.weight 780 g/l, TSW 327 g

Bottom flaps: 5. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel										
6.00 5.00	1	17	19	21	23	25				
-16 -15										
30 27	4,47	76	85	94	103	112				
33 30	4,89	83	93	103	112	122				
36 33	5,34	91	101	112	123	133				
39 35	5,76	98	109	121	132	144				
42 38	6,25	106	119	131	144	156				
45 41	6,67	113	127	140	153	167				
48 44	7,15	122	136	150	165	179				
51 45	7,65	130	145	161	176	191				
54 48	8,11	138	154	170	186	203				
57 52	8,76	149	166	184	201	219				
60 54	9,05	154	172	190	208	226				
63 57	9,60	163	182	202	221	240				
66 60	10,13	172	193	213	233	253				
69 63	10,63	181	202	223	244	266				
72 65	11,67	190	212	235	257	279				
75 68	11,52	196	219	242	265	288				
78 71	12,30	209	234	258	283	307				
81 73	12,88	219	245	270	296	322				
84 76	13,35	227	254	280	307	334				
87 79	14,00	239	267	295	323	351				
90 82	14,40	245	274	302	331	360				
93 84	15,20	268	289	319	350	380				
96 87	15,64	266	297	328	360	391				
99 90	16,34	278	310	343	376	408				
102 92	17,10	291	325	359	393	428				
105 94	17,65	300	335	371	406	441				
108 97	18,24	310	347	383	420	456				
111 99	18,87	321	359	396	434	472				
114 102	19,90	338	378	418	458	498				
117 105	20,27	345	385	426	466	507				

Demeter Classic CS/CSA 2500 (2,5 m)

Rape, L.weight 617 g/l

Bottom flaps: 1. pos

Seed shutter: 1. pos

Fine seed roller

Cut-off agitator shaft

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel										
6.00 5.00	1	17	19	21	23	25				
-16 -15										
9 8	0,09	1,5	1,7	1,9	2,1	2,3				
12 11	0,12	2,1	2,3	2,6	2,8	3,1				
15 14	0,14	2,7	3,0	3,2	3,5	3,8				
18 18	0,18	3,0	3,3	3,7	4,0	4,4				
21 20	0,19	3,3	3,7	4,1	4,4	4,8				
24 22	0,22	3,7	4,1	4,5	5,0	5,4				
27 25	0,24	4,1	4,6	5,1	5,6	6,1				
30 27	0,27	4,6	5,1	5,6	6,2	6,7				
33 30	0,29	5,0	5,6	6,2	6,7	7,0				
36 33	0,32	5,4	6,1	6,7	7,4	8,0				
39 35	0,35	5,9	6,6	7,3	7,9	8,6				
42 38	0,38	6,4	7,1	7,9	8,6	9,4				
45 41	0,40	6,8	7,6	8,4	9,2	10,0				
48 44	0,43	7,3	8,2	9,0	9,9	10,7				
51 45	0,46	7,8	8,7	9,6	10,6	11,5				
54 48	0,49	8,3	9,2	10,2	11,2	12,2				
57 52	0,53	8,9	10,0	11,0	12,1	13,1				
60 54	0,54	9,2	10,3	11,4	12,5	13,6				
63 57	0,58	9,8	10,9	12,1	13,2	14,4				
66 60	0,61	10,3	11,6	12,8	14,0	15,2				
69 63	0,64	10,8	12,1	13,4	14,7	15,9				
72 65	0,67	11,4	12,7	14,1	15,4	16,8				
75 68	0,69	11,8	13,1	14,5	15,9	17,3				
78 71	0,74	12,5	14,0	15,5	17,0	18,4				
81 73	0,77	13,1	14,7	16,2	17,8	19,3				
84 76	0,80	13,6	15,2	16,8	18,4	20,0				
87 79	0,84	14,3	16,0	17,7	19,4	21,0				
90 82	0,86	14,7	16,4	18,1	19,9	21,6				
93 84	0,91	15,5	17,3	19,2	21,0	22,8				
96 87	0,94	15,9	17,8	19,7	21,6	23,5				

Demeter Classic CS/CSA 2500 (2,5 m)

Graas, L.weight 324 g/l

Bottom flaps: 1. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha										
	Number of rows										
Tyred wheel	1	17	19	21	23	25					
6.00	5.00										
-16	-15										
15	14	0,56	9,4	10,6	11,7	12,8	13,9				
18	18	0,69	11,8	13,2	14,5	15,9	17,3				
21	20	0,76	12,9	14,4	16,0	17,5	19,0				
24	22	0,85	14,4	16,1	17,8	19,5	21,2				
27	25	0,96	16,3	18,2	20,1	22,0	23,9				
30	27	1,05	17,9	20,0	22,1	24,2	26,4				
33	30	1,15	19,6	21,9	24,2	26,5	28,8				
36	33	1,26	21,4	23,9	26,5	29,0	31,5				
39	35	1,36	23,1	25,8	28,5	31,3	34,0				
42	38	1,48	25,1	28,0	31,0	33,9	36,9				
45	41	1,58	26,8	29,9	33,1	36,2	39,4				
48	44	1,69	28,7	32,1	35,5	38,8	42,2				
51	45	1,81	30,7	34,3	37,9	41,5	45,2				
54	48	1,91	32,5	36,4	40,2	44,0	47,8				
57	52	2,07	35,1	39,4	43,4	47,5	51,7				
60	54	2,13	36,3	40,6	44,8	49,1	53,4				
63	57	2,27	38,5	43,1	47,6	52,1	56,6				
66	60	2,39	40,7	45,4	50,2	55,0	59,8				
69	63	2,51	42,6	47,6	52,7	57,7	62,7				
72	65	2,64	44,8	50,1	55,4	60,6	65,9				
75	68	2,72	46,2	51,7	57,1	62,5	68,0				
78	71	2,90	49,3	55,1	60,9	66,8	72,6				
81	73	3,04	51,7	57,7	63,8	69,9	76,0				
84	76	3,15	53,6	59,9	66,2	72,5	78,8				
87	79	3,31	56,3	62,9	69,5	76,2	82,8				
90	82	3,40	57,8	64,6	71,4	78,2	85,0				
93	84	3,59	61,0	68,2	75,3	82,5	89,7				
96	87	3,69	62,7	70,1	77,5	84,9	92,3				
99	90	3,86	65,5	73,2	81,0	88,7	96,4				
102	92	4,04	68,6	76,7	84,8	92,8					

Seedtable

DEMETER CLASSIC

CS/CSA 3000 (3,0 m)

Type	Tyred wheel	Calibration of the level			
		1 Ha	1/4 Ha	1/10 Ha	1/40 Ha
CS	5.00 - 15	4242	1060	424,2	106
	6.00 - 16	3648	912	364,8	91,2
CS-A	Land wheel	3648	912	364,8	91,2

Demeter Classic CS/CSA 3000 (3,0 m)

Wheat, L. weight 880 g/l, TSW 48 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha												
	Number of rows												
Tyred wheel													
6.00 5.00	1	19	21	23	25	27	29	29	35				
-16 -15													
24 22	3,23	61	68	74	81	87	94	113					
27 25	3,65	69	77	84	91	98	106	128					
30 27	4,02	76	84	92	101	109	117	141					
33 30	4,40	84	92	101	110	119	128	154					
36 33	4,80	91	101	111	120	130	139	168					
39 35	5,18	98	109	119	130	140	150	181					
42 38	5,63	107	118	129	141	152	163	197					
45 41	6,01	114	126	138	150	162	174	210					
48 44	6,44	122	135	148	161	174	187	225					
51 45	6,89	131	145	158	172	186	200	241					
54 48	7,30	139	153	168	182	197	212	255					
57 52	7,88	150	165	181	197	213	229	276					
60 54	8,14	155	171	187	204	220	236	285					
63 57	8,64	164	181	199	216	233	251	302					
66 60	9,12	173	192	210	228	246	264	319					
69 63	9,56	182	201	220	239	258	277	335					
72 65	10,05	191	211	231	251	271	291	352					
75 68	10,37	197	218	238	259	280	301	363					
78 71	11,07	210	232	255	277	299	321	387					
81 73	11,59	220	243	267	290	313	336	406					
84 76	12,01	228	252	276	300	324	348	420					
87 79	12,63	240	265	290	316	341	366	442					
90 82	12,96	246	272	298	324	350	376	454					
93 84	13,68	260	287	315	342	369	397	479					
96 87	14,07	267	295	324	352	380	408	492					
99 90	14,70	279	309	338	368	397	426	515					
102 92	15,39	292	323	354	385	416	446	539					
105 94	15,89	302	334	365	397	429	461	556					
108 97	16,42	312	345	378	410	443	476	575					
111 99	16,98	323	357	391	425	459	492	594					

Demeter Classic CS/CSA 3000 (3,0 m)

Barley, L. weight 797 g/l, TSW 52 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha												
	Number of rows												
Tyred wheel													
6.00 5.00	1	19	21	23	25	27	29	29	35				
-16 -15													
24 22	2,64	50	56	61	66	71	77	93					
27 25	2,99	57	63	69	75	81	87	105					
30 27	3,29	63	69	76	82	89	95	115					
33 30	3,60	68	76	83	90	97	104	126					
36 33	3,93	75	83	90	98	106	114	138					
39 35	4,24	81	89	98	106	115	123	149					
42 38	4,61	88	97	106	115	124	134	161					
45 41	4,92	93	103	113	123	133	143	172					
48 44	5,27	100	111	121	132	142	153	184					
51 45	5,64	107	118	130	141	152	163	197					
54 48	5,97	113	125	137	149	161	173	209					
57 52	6,45	123	135	148	161	174	187	226					
60 54	6,66	127	140	153	167	180	193	233					
63 57	7,07	134	149	163	177	191	205	248					
66 60	7,46	142	157	172	187	202	216	261					
69 63	7,83	149	164	180	196	211	227	274					
72 65	8,23	156	173	189	206	222	239	288					
75 68	8,49	161	178	195	212	229	246	297					
78 71	9,06	172	190	208	226	245	263	317					
81 73	9,48	180	199	218	237	256	275	332					
84 76	9,83	187	206	226	246	265	285	344					
87 79	10,34	196	217	238	258	279	300	362					
90 82	10,61	202	223	244	265	286	308	371					
93 84	11,20	213	235	258	280	302	325	392					
96 87	11,52	219	242	265	288	311	334	403					
99 90	12,03	229	253	277	301	325	349	421					
102 92	12,60	239	265	290	315	340	365	441					
105 94	13,00	247	273	299	325	351	377	455					
108 97	13,44	255	282	309	336	363	390	470					
111 99	13,90	264	292	320	348	375	403	487					

Demeter Classic CS/CSA 3000 (3,0 m)

Oats, L.weight 552 g/l, TSW 38 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha											
	Number of rows											
Tyred wheel	6,00	5,00	-16	-15	1	19	21	23	25	27	29	35
63	57	4,96	94	104	114	124	134	144	154	164	174	184
66	60	5,24	99	110	120	131	141	152	163	174	185	196
69	63	5,49	104	115	126	137	148	159	170	181	192	203
72	65	5,77	110	121	133	144	156	167	179	191	203	215
75	68	5,95	113	125	137	149	161	173	186	200	214	228
78	71	6,35	121	133	146	159	172	184	200	216	233	250
81	73	6,65	126	140	153	166	180	193	210	228	246	264
84	76	6,90	131	145	159	172	186	200	218	236	254	272
87	79	7,25	138	152	167	181	196	210	228	246	264	282
90	82	7,44	141	156	171	186	201	216	233	250	267	284
93	84	7,85	149	165	181	196	212	228	246	264	282	300
96	87	8,08	153	170	186	202	218	234	251	268	285	302
99	90	8,44	160	177	194	211	228	245	263	280	297	314
102	92	8,84	168	186	203	221	239	256	274	292	310	328
105	94	9,12	173	192	210	228	246	264	282	300	318	336
108	97	9,42	179	198	217	236	254	273	291	310	328	346
111	99	9,75	185	205	224	244	263	283	301	320	339	358
114	102	10,28	195	216	236	257	278	298	318	338	358	378
117	105	10,47	199	220	241	262	283	304	324	345	365	386
120	109	10,87	207	228	250	272	294	315	336	357	378	399
123	112	11,31	215	237	260	283	305	328	350	373	396	419
126	114	11,78	224	247	271	295	318	342	365	389	413	437
129	117	12,03	229	253	277	301	325	349	373	397	421	445
132	120	12,57	239	264	289	314	339	364	389	414	439	464
135	123	12,85	244	270	296	321	347	373	400	426	452	478
138	126	13,46	256	283	310	337	363	390	417	444	471	498
141	129	13,79	262	290	317	345	372	400	428	455	483	511
144	132	14,14	269	297	325	353	382	410	439	467	496	525
147	134	14,69	279	308	338	367	397	426	455	484	514	544
150	137	15,00	285	315	345	375	405	435	465	495	525	555

Demeter Classic CS/CSA 3000 (3,0 m)

Rye, L.weight 775 g/l, TSW 40 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha											
	Number of rows											
Tyred wheel	6,00	5,00	-16	-15	1	19	21	23	25	27	29	35
24	22	2,67	51	56	61	67	72	77	83	88	93	99
27	25	3,01	57	63	69	75	81	87	93	99	105	111
30	27	3,32	63	70	76	83	90	96	103	110	117	124
33	30	3,63	69	76	84	91	98	105	113	120	127	134
36	33	3,97	75	83	91	99	107	115	123	131	139	147
39	35	4,28	81	90	98	107	116	124	133	142	150	159
42	38	4,65	88	98	107	116	126	135	144	154	163	173
45	41	4,96	94	104	114	124	134	144	154	164	174	184
48	44	5,32	101	112	122	133	144	154	164	174	184	194
51	45	5,69	108	119	131	142	154	165	176	187	199	211
54	48	6,03	114	127	139	151	163	175	188	201	214	227
57	52	6,51	124	137	150	163	176	189	202	215	228	241
60	54	6,72	128	141	155	168	182	195	208	221	235	248
63	57	7,14	136	150	164	178	193	207	220	234	248	262
66	60	7,53	143	158	173	188	203	218	232	247	261	276
69	63	7,90	150	166	182	197	213	229	244	259	274	289
72	65	8,30	158	174	191	208	224	241	257	273	289	305
75	68	8,56	163	180	197	214	231	248	265	282	299	316
78	71	9,14	174	192	210	229	247	265	283	301	319	337
81	73	9,57	182	201	220	239	258	278	297	316	335	354
84	76	9,92	188	208	228	248	268	288	308	328	347	367
87	79	10,43	198	219	240	261	282	302	322	342	362	382
90	82	10,70	203	225	246	268	289	310	330	350	370	390
93	84	11,30	215	237	260	282	305	328	350	373	395	417
96	87	11,62	221	244	267	291	314	337	360	383	405	428
99	90	12,14	231	255	279	304	328	352	376	400	424	448
102	92	12,71	242	267	292	318	343	369	394	419	445	470
105	94	13,12	249	276	302	328	354	381	407	433	459	485
108	97	13,56	258	285	312	339	366	393	420	447	474	501
111	99	14,03	266	295	323	351	379	407	435	463	491	519

Demeter Classic CS/CSA 3000 (3,0 m)

Graas, L.weight 324 g/l

Bottom flaps: 1. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha																		
	Number of rows																		
Tyred wheel	1	19	21	23	25	27	29	35											
6.00	5.00																		
-16	-15																		
15	14	0,46	8,8	9,7	10,6	11,6	12,5	13,4	16,2										
18	18	0,58	11,0	12,1	13,3	14,4	15,6	16,7	20,2										
21	20	0,63	12,0	13,3	14,6	15,8	17,1	18,4	22,2										
24	22	0,71	13,4	14,8	16,2	17,6	19,1	20,5	24,7										
27	25	0,80	15,1	16,7	18,3	19,9	21,5	23,1	27,9										
30	27	0,88	16,7	18,4	20,2	22,0	23,7	25,5	30,7										
33	30	0,96	18,3	20,2	22,1	24,0	25,9	27,9	33,6										
36	33	1,05	19,9	22,0	24,1	26,2	28,3	30,4	36,7										
39	35	1,13	21,5	23,8	26,1	28,3	30,6	32,9	39,6										
42	38	1,23	23,4	25,8	28,3	30,7	33,2	35,7	43,0										
45	41	1,31	24,9	27,6	30,2	32,8	35,4	38,1	45,9										
48	44	1,41	26,7	29,5	32,4	35,2	38,0	40,8	49,2										
51	45	1,51	28,6	31,6	34,6	37,6	40,6	43,6	52,7										
54	48	1,59	30,3	33,5	36,7	39,9	43,0	46,2	55,8										
57	52	1,72	32,7	36,2	39,6	43,0	46,5	49,9	60,3										
60	54	1,78	33,8	37,4	40,9	44,5	48,0	51,6	62,3										
63	57	1,89	35,9	39,6	43,4	47,2	51,0	54,8	66,1										
66	60	1,99	37,9	41,9	45,8	49,8	53,8	57,8	69,8										
69	63	2,09	39,7	43,9	48,1	52,2	56,4	60,6	73,1										
72	65	2,20	41,7	46,1	50,5	54,9	59,3	63,7	76,9										
75	68	2,27	43,0	47,6	52,1	56,6	61,2	65,7	79,3										
78	71	2,42	45,9	50,8	55,6	60,5	65,3	70,1	84,6										
81	73	2,53	48,1	53,2	58,2	63,3	68,4	73,4	88,6										
84	76	2,62	49,9	55,1	60,4	65,6	70,9	76,1	91,9										
87	79	2,76	52,4	57,9	63,5	69,0	74,5	80,0	96,6										
90	82	2,83	53,8	59,5	65,1	70,8	76,5	82,1	99,1										
93	84	2,99	56,8	62,8	68,8	74,7	80,7	86,7	99,1										
96	87	3,07	58,4	64,6	70,7	76,9	83,0	89,2	99,1										
99	90	3,21	61,0	67,5	73,9	80,3	86,7	93,2	99,1										
102	92	3,36	63,9	70,6	77,3	84,1	90,8	97,5	99,1										

Seedtable

DEMETER CLASSIC

CS/CSA 4000 (4,0 m)

Type	Tyred wheel	Calibration of the level			
		1 Ha	1/4 Ha	1/10 Ha	1/40 Ha
CS	10.00 - 15	2815	704	281,5	70,4
CS-A	Land wheel	2736	684	273,6	68,4

Demeter Classic CS/CSA 4000 (4,0 m)

Wheat, L.weight 880 g/l, TSW 48 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel										
10,00	1	29	31	33	35	39				
-15										
30	2,94	85	91	97	103	115				
33	3,21	93	100	106	112	125				
36	3,51	102	109	116	123	137				
39	3,79	110	117	125	133	148				
42	4,11	119	127	136	144	160				
45	4,39	127	136	145	154	171				
48	4,70	136	146	155	165	183				
51	5,03	146	156	166	176	196				
54	5,33	155	165	176	187	208				
57	5,76	167	178	190	201	224				
60	5,95	172	184	196	208	232				
63	6,31	183	196	208	221	246				
66	6,66	193	207	220	233	260				
69	6,99	203	217	231	245	272				
72	7,34	213	228	242	257	286				
75	7,57	220	235	250	265	295				
78	8,08	234	251	267	283	315				
81	8,47	245	262	279	296	330				
84	8,77	254	272	290	307	342				
87	9,23	268	286	304	323	360				
90	9,47	275	294	312	331	369				
93	9,99	290	310	330	350	390				
96	10,28	298	319	339	360	401				
99	10,74	311	333	354	376	419				
102	11,24	326	349	371	394	438				
105	11,61	337	360	383	406	453				
108	11,99	348	372	396	420	468				
111	12,41	360	385	409	434	484				
114	13,08	379	406	432	458	510				

Demeter Classic CS/CSA 4000 (4,0 m)

Barley, L.weight 797 g/l, TSW 52 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel										
10,00	1	29	31	33	35	39				
-15										
30	2,40	70	75	79	84	94				
33	2,63	76	82	87	92	103				
36	2,87	83	89	95	101	112				
39	3,10	90	96	102	108	121				
42	3,37	98	104	111	118	131				
45	3,59	104	111	119	126	140				
48	3,85	112	119	127	135	150				
51	4,12	119	128	136	144	161				
54	4,36	127	135	144	153	170				
57	4,71	137	146	155	165	184				
60	4,85	141	151	161	170	190				
63	5,17	150	160	170	181	201				
66	5,45	158	169	180	191	213				
69	5,72	166	177	189	200	223				
72	6,01	174	186	198	210	234				
75	6,20	180	192	205	217	242				
78	6,62	192	205	218	232	258				
81	6,93	201	215	229	243	270				
84	7,18	208	223	237	251	280				
87	7,55	219	234	249	264	294				
90	7,75	225	240	256	271	302				
93	8,18	237	254	270	286	319				
96	8,41	244	261	278	294	328				
99	8,79	255	273	290	308	343				
102	9,20	267	285	304	322	359				
105	9,50	275	294	313	332	370				
108	9,82	285	304	324	344	383				
111	10,15	294	315	335	355	396				
114	10,71	311	332	353	375	418				

Demeter Classic CS/CSA 4000 (4,0 m)

Peas, L.weight 780 g/l, TSW 327 g

Bottom flaps: 5. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel 10,00 -15	1	29	31	33	35	39				
30	2,72	79	84	90	95	106				
33	2,97	86	92	98	104	116				
36	3,25	94	101	107	114	127				
39	3,51	102	109	116	123	137				
42	3,81	110	118	126	133	148				
45	4,06	118	126	134	142	158				
48	4,35	126	135	144	152	170				
51	4,66	135	144	154	163	182				
54	4,94	143	153	163	173	192				
57	5,33	155	165	176	187	208				
60	5,51	160	171	182	193	215				
63	5,84	169	181	193	205	228				
66	6,17	179	191	204	216	241				
69	6,47	188	201	213	226	252				
72	6,80	197	211	224	238	265				
75	7,01	203	217	231	245	274				
78	7,49	217	232	247	262	292				
81	7,84	227	243	259	274	306				
84	8,13	236	252	268	284	317				
87	8,54	248	265	282	299	333				
90	8,77	254	272	289	307	342				
93	9,25	268	287	305	324	361				
96	9,52	276	295	314	333	371				
99	9,94	288	308	328	348	388				
102	10,41	302	323	344	364	406				
105	10,75	312	333	355	376	419				
108	11,10	322	344	366	389	433				
111	11,49	333	356	379	402	448				
114	12,11	351	376	400	424	472				

Demeter Classic CS/CSA 4000 (4,0 m)

Rape, L.weight 617 g/l

Bottom flaps: 1. pos

Seed shutter: 1. pos

Fine seed roller

Cut-off agitator shaft

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel 10,00 -15	1	29	31	33	35	39				
9	0,06	1,6	1,7	1,8	1,9	2,2				
12	0,08	2,2	2,3	2,5	2,6	2,9				
15	0,09	2,5	2,7	2,8	3,0	3,4				
18	0,11	3,1	3,3	3,5	3,8	4,2				
21	0,12	3,4	3,6	3,9	4,1	4,6				
24	0,13	3,8	4,1	4,3	4,6	5,1				
27	0,15	4,3	4,6	4,9	5,2	5,8				
30	0,16	4,7	5,1	5,4	5,7	6,4				
33	0,18	5,2	5,5	5,9	6,2	7,0				
36	0,20	5,7	6,0	6,4	6,8	7,6				
39	0,21	6,1	6,5	6,9	7,4	8,2				
42	0,23	6,6	7,1	7,5	8,0	8,9				
45	0,24	7,1	7,6	8,0	8,5	9,5				
48	0,26	7,6	8,1	8,6	9,1	10,2				
51	0,28	8,1	8,7	9,2	9,8	10,9				
54	0,30	8,6	9,2	9,8	10,4	11,5				
57	0,32	9,3	9,9	10,6	11,2	12,5				
60	0,33	9,6	10,2	10,9	11,6	12,9				
63	0,35	10,2	10,9	11,6	12,3	13,7				
66	0,37	10,7	11,5	12,2	13,0	14,4				
69	0,39	11,3	12,0	12,8	13,6	15,1				
72	0,41	11,8	12,6	13,5	14,3	15,9				
75	0,42	12,2	13,0	13,9	14,7	16,4				
78	0,45	13,0	13,9	14,8	15,7	17,5				
81	0,47	13,6	14,6	15,5	16,5	18,3				
84	0,49	14,1	15,1	16,1	17,1	19,0				
87	0,51	14,9	15,9	16,9	17,9	20,0				
90	0,53	15,3	16,3	17,4	18,4	20,5				
93	0,56	16,1	17,2	18,3	19,4	21,7				

Seedtable

DEMETER CLASSIC

CS/CSA 4500 (4,5 m)

Type	Tyred wheel	Calibration of the level			
		1 Ha	1/4 Ha	1/10 Ha	1/40 Ha
CS	10.00 - 15	2467	617	247	62
CS-A	Land wheel	2432	608	243,2	60,8

Demeter Classic CS/CSA 4500 (4,5 m)

Wheat, L.weight 880 g/l, TSW 48 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel 10,00 -15	1	29	31	33	35	39				
33	2,86	83	89	94	100	111				
36	3,12	90	97	103	109	122				
39	3,37	98	104	111	118	131				
42	3,66	106	113	121	128	143				
45	3,90	113	121	129	137	152				
48	4,18	121	130	138	146	163				
51	4,47	130	139	148	157	174				
54	4,74	137	147	156	166	185				
57	5,12	148	159	169	179	200				
60	5,29	153	164	174	185	206				
63	5,61	163	174	185	196	219				
66	5,92	172	184	195	207	231				
69	6,21	180	193	205	217	242				
72	6,53	189	202	215	228	255				
75	6,73	195	209	222	236	263				
78	7,19	208	223	237	252	280				
81	7,53	218	233	248	263	293				
84	7,80	226	242	257	273	304				
87	8,20	238	254	271	287	320				
90	8,42	244	261	278	295	328				
93	8,88	258	275	293	311	346				
96	9,14	265	283	302	320	356				
99	9,55	277	296	315	334	372				
102	9,99	290	310	330	350	390				
105	10,32	299	320	340	361	402				
108	10,66	309	330	352	373	416				
111	11,03	320	342	364	386	430				
114	11,63	337	361	384	407	454				

Demeter Classic CS/CSA 4500 (4,5 m)

Barley, L.weight 797 g/l, TSW 52 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel 10,00 -15	1	29	31	33	35	39				
33	2,34	68	72	77	82	91				
36	2,55	74	79	84	89	100				
39	2,76	80	85	91	96	107				
42	2,99	87	93	99	105	117				
45	3,19	93	99	105	112	125				
48	3,42	99	106	113	120	133				
51	3,66	106	113	121	128	143				
54	3,88	112	120	128	136	151				
57	4,19	121	130	138	147	163				
60	4,33	125	134	143	151	169				
63	4,59	133	142	152	161	179				
66	4,85	141	150	160	170	189				
69	5,08	147	158	168	178	198				
72	5,34	155	166	176	187	208				
75	5,51	160	171	182	193	215				
78	5,88	171	182	194	206	229				
81	6,16	179	191	203	216	240				
84	6,38	185	198	211	223	249				
87	6,71	195	208	222	235	262				
90	6,89	200	214	227	241	269				
93	7,27	211	225	240	255	284				
96	7,48	217	232	247	262	292				
99	7,81	227	242	258	273	305				
102	8,18	237	254	270	286	319				
105	8,44	245	262	279	296	329				
108	8,73	253	271	288	305	340				
111	9,03	262	280	298	316	352				
114	9,52	276	295	314	333	371				
117	9,70	281	301	320	339	378				

Demeter Classic CS/CSA 4500 (4,5 m)

Oats, L.weight 552 g/l, TSW 38 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel										
10,00	1	29	31	33	35	39				
-15										
66	3,40	99	105	112	119	133				
69	3,57	103	111	118	125	139				
72	3,75	109	116	124	131	146				
75	3,87	112	120	128	135	151				
78	4,13	120	128	136	144	161				
81	4,32	125	134	143	151	168				
84	4,48	130	139	148	157	175				
87	4,71	137	146	155	165	184				
90	4,83	140	150	159	169	188				
93	5,10	148	158	168	178	199				
96	5,25	152	163	173	184	205				
99	5,48	159	170	181	192	214				
102	5,74	166	178	189	201	224				
105	5,92	172	184	195	207	231				
108	6,12	177	190	202	214	239				
111	6,33	184	196	209	222	247				
114	6,68	194	207	220	234	260				
117	6,80	197	211	224	238	265				
120	7,06	205	219	233	247	275				
123	7,34	213	228	242	257	286				
126	7,65	222	237	252	268	298				
129	7,81	227	242	258	273	305				
132	8,16	237	253	269	286	318				
135	8,35	242	259	275	292	325				
138	8,74	254	271	289	306	341				
141	8,96	260	278	296	313	349				
144	9,18	266	285	303	321	358				
147	9,54	277	296	315	334	372				
150	9,74	282	302	321	341	380				

Demeter Classic CS/CSA 4500 (4,5 m)

Rye, L.weight 775 g/l, TSW 40 g

Bottom flaps: 2. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel										
10,00	1	29	31	33	35	39				
-15										
33	2,36	68	73	78	83	92				
36	2,58	75	80	85	90	101				
39	2,78	81	86	92	97	108				
42	3,02	88	94	100	106	118				
45	3,22	93	100	106	113	126				
48	3,45	100	107	114	121	135				
51	3,69	107	115	122	129	144				
54	3,91	113	121	129	137	153				
57	4,23	123	131	139	148	165				
60	4,37	127	135	144	153	170				
63	4,63	134	144	153	162	181				
66	4,89	142	152	161	171	191				
69	5,13	149	159	169	180	200				
72	5,39	156	167	178	189	210				
75	5,56	161	172	184	195	217				
78	5,94	172	184	196	208	231				
81	6,22	180	193	205	218	242				
84	6,44	187	200	213	225	251				
87	6,77	196	210	224	237	264				
90	6,95	202	215	229	243	271				
93	7,34	213	227	242	257	286				
96	7,55	219	234	249	264	294				
99	7,88	229	244	260	276	308				
102	8,25	239	256	272	289	322				
105	8,52	247	264	281	298	332				
108	8,80	255	273	291	308	343				
111	9,11	264	282	301	319	355				
114	9,61	279	298	317	336	375				

Demeter Classic CS/CSA 4500 (4,5 m)

Peas, L.weight 780 g/l, TSW 327 g

Bottom flaps: 5. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel 10,00 -15	1	29	31	33	35	39				
33	2,64	77	82	87	93	103				
36	2,89	84	90	95	101	113				
39	3,12	90	97	103	109	122				
42	3,38	98	105	112	118	132				
45	3,61	105	112	119	126	141				
48	3,87	112	120	128	135	151				
51	4,14	120	128	137	145	162				
54	4,39	127	136	145	154	171				
57	4,74	137	147	156	166	185				
60	4,89	142	152	162	171	191				
63	5,20	151	161	171	182	203				
66	5,48	159	170	181	192	214				
69	5,75	167	178	190	201	224				
72	6,04	175	187	199	212	236				
75	6,23	181	193	206	218	243				
78	6,65	193	206	220	233	260				
81	6,97	202	216	230	244	272				
84	7,22	209	224	238	253	282				
87	7,59	220	235	251	266	296				
90	7,79	226	242	257	273	304				
93	8,23	239	255	271	288	321				
96	8,46	245	262	279	296	330				
99	8,84	256	274	292	309	345				
102	9,25	268	287	305	324	361				
105	9,55	277	296	315	334	373				
108	9,87	286	306	326	345	385				
111	10,21	296	317	337	357	398				
114	10,77	312	334	355	377	420				
117	10,97	318	340	362	384	428				

Demeter Classic CS/CSA 4500 (4,5 m)

Rape, L.weight 617 g/l

Bottom flaps: 1. pos

Seed shutter: 1. pos

Fine seed roller

Cut-off agitator shaft

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel 10,00 -15	1	29	31	33	35	39				
9	0,04	1,2	1,3	1,4	1,5	1,7				
12	0,06	1,7	1,8	1,9	2,0	2,3				
15	0,07	1,9	2,1	2,2	2,3	2,6				
18	0,08	2,4	2,6	2,7	2,9	3,2				
21	0,09	2,6	2,8	3,0	3,2	3,5				
24	0,10	2,9	3,1	3,3	3,5	3,9				
27	0,11	3,3	3,5	3,8	4,0	4,4				
30	0,13	3,6	3,9	4,1	4,4	4,9				
33	0,14	4,0	4,3	4,5	4,8	5,4				
36	0,15	4,4	4,7	5,0	5,3	5,9				
39	0,16	4,7	5,0	5,3	5,7	6,3				
42	0,18	5,1	5,5	5,8	6,2	6,9				
45	0,19	5,4	5,8	6,2	6,6	7,3				
48	0,20	5,8	6,2	6,6	7,0	7,9				
51	0,22	6,2	6,7	7,1	7,5	8,4				
54	0,23	6,6	7,1	7,5	8,0	8,9				
57	0,25	7,1	7,6	8,1	8,6	9,6				
60	0,25	7,4	7,9	8,4	8,9	9,9				
63	0,27	7,8	8,4	8,9	9,5	10,5				
66	0,29	8,3	8,8	9,4	10,0	11,1				
69	0,30	8,7	9,3	9,9	10,5	11,7				
72	0,31	9,1	9,7	10,4	11,0	12,3				
75	0,32	9,4	10,0	10,7	11,3	12,6				
78	0,35	10,0	10,7	11,4	12,1	13,5				
81	0,36	10,5	11,2	12,0	12,7	14,1				
84	0,38	10,9	11,6	12,4	13,1	14,6				
87	0,39	11,5	12,2	13,0	13,8	15,4				
90	0,41	11,8	12,6	13,4	14,2	15,8				
93	0,43	12,4	13,3	14,1	15,0	16,7				

Demeter Classic CS/CSA 4500 (4,5 m)

Graas, L. weight 324 g/l

Bottom flaps: 1. pos

Seed shutter: 2. pos

Full seed roller

Adjustment of Gear Box	Quantity of seed distributed kg/ha									
	Number of rows									
Tyred wheel	1	29	31	33	35	39				
10,00										
-15										
18	0,37	10,9	11,6	12,4	13,1	14,6				
21	0,41	11,9	12,7	13,6	14,4	16,0				
24	0,46	13,3	14,2	15,1	16,0	17,9				
27	0,52	15,0	16,0	17,1	18,1	20,2				
30	0,57	16,5	17,7	18,8	20,0	22,2				
33	0,62	18,1	19,3	20,6	21,8	24,3				
36	0,68	19,8	21,1	22,5	23,9	26,6				
39	0,74	21,3	22,8	24,3	25,7	28,7				
42	0,80	23,2	24,8	26,4	28,0	31,1				
45	0,85	24,7	26,4	28,1	29,8	33,2				
48	0,91	26,5	28,3	30,1	32,0	35,6				
51	0,98	28,3	30,3	32,3	34,2	38,1				
54	1,04	30,0	32,1	34,2	36,2	40,4				
57	1,12	32,4	34,7	36,9	39,1	43,6				
60	1,16	33,5	35,8	38,1	40,4	45,1				
63	1,23	35,6	38,0	40,5	42,9	47,8				
66	1,29	37,5	40,1	42,7	45,3	50,5				
69	1,36	39,4	42,1	44,8	47,5	52,9				
72	1,43	41,4	44,2	47,1	49,9	55,6				
75	1,47	42,7	45,6	48,6	51,5	57,4				
78	1,57	45,5	48,7	51,8	55,0	61,2				
81	1,64	47,7	51,0	54,3	57,6	64,1				
84	1,70	49,4	52,8	56,2	59,7	66,5				
87	1,79	52,0	55,6	59,1	62,7	69,9				
90	1,84	53,3	57,0	60,7	64,4	71,7				
93	1,94	56,3	60,2	64,1	67,9	75,7				
96	2,00	57,9	61,9	65,9	69,9	77,9				
99	2,09	60,5	64,7	68,8	73,0	81,4				
102	2,18	63,3	67,7	72,1	76,4	85,2				

