



VIBRO TILL 2800 **FIELD CULTIVATOR**

Kongsilde
2800 Series



***Model may not be exactly as shown.**

Kongsilde reserves the right to make changes to product designs and specifications without notice or obligation to rework. Levelling attachments pictured on above unit sold separately. See your local Kongsilde representative for current product specifications and options.

Tine Pattern Layouts

Index

Introduction.....3

10' Center / 16'8" Wide 4" Tine spacing 51 Tines4

10' Center / 20'0" Wide 4" Tine spacing 61 Tines5

10' Center / 23'4" Wide 4" Tine spacing 71 Tines6

10' Center / 26'8" Wide 4" Tine spacing 81 Tines7

10' Center / 16'8" Wide 6" Tine spacing 33 Tines8

10' Center / 20'0" Wide 6" Tine spacing 39 Tines9

10" Center / 23'4" Wide 6" Tine spacing 47 Tines10

10' Center / 26'8" Wide 6" Tine spacing 53 Tines11

13' Center / 23'4" Wide 4" Tine spacing 71 Tines12

13' Center / 26'8" Wide 4" Tine spacing 81 Tines13

13' Center / 29'10" Wide 4" Tine spacing 91 Tines14

13' Center / 33'2" Wide 4" Tine spacing 101 Tines15

13" Center / 23'4" Wide 6" Tine spacing 47 Tines16

13' Center / 26'8" Wide 6" Tine spacing 53 Tines17

13' Center / 29'10" Wide 6" Tine spacing 59 Tines18

13" Center / 33'2" Wide 6" Tine spacing 65 Tines19

Notes20

2800 Vibro -Till Assembly Supplement:

This Booklet is meant as a supplement to the 2800 Vibro-Till assembly manual.

Use this tine pattern booklet, the parts book and the 2800 Vibro-Till assembly manual as you assemble the Vibro-Till Unit.

Tine Pattern Reference Section:

Tines Patterns in this booklet are organized by machine model and spacing as follows:

10' (3m) Centre and Wings - 4" patterns

10' (3m) Centre and Wings - 6" patterns


13' (4m) Centre and Wings - 4" patterns

13' (4m) Centre and Wings - 6" patterns


Measure Centre Sections from Left side of frame as indicated by "0" line .

Measure Wings from outside of frame at front and rear as indicated by "0" lines.


CULTIVATOR SIZE
10' CENTRE / 16'8" WIDE
4" TINE SPACING 51 TINES




CULTIVATOR SIZE
10' CENTRE / 20'0" WIDE
4" TINE SPACING 61 TINES




CULTIVATOR SIZE
10' CENTRE / 23'4" WIDE
4" TINE SPACING 71 TINES




CULTIVATOR SIZE
 10' CENTRE / 26'8" WIDE
 4" TINE SPACING 81 TINES




CULTIVATOR SIZE
10' CENTRE / 16'8" WIDE
6" TINE SPACING 33 TINES




CULTIVATOR SIZE
 10' CENTRE / 20'0" WIDE
 6" TINE SPACING 39 TINES




CULTIVATOR SIZE
10' CENTRE / 23'4" WIDE
6" TINE SPACING 47 TINES




CULTIVATOR SIZE
10' CENTRE / 26'8" WIDE
6" TINE SPACING 53 TINES




CULTIVATOR SIZE
13' CENTRE / 23'4" WIDE
4" TINE SPACING 71 TINES




CULTIVATOR SIZE
13' CENTRE / 26'8" WIDE
4" TINE SPACING 81 TINES




CULTIVATOR SIZE
13' CENTRE / 29'10" WIDE
4" TINE SPACING 91 TINES




CULTIVATOR SIZE
13' CENTRE / 33 1/2" WIDE
4" TINE SPACING 101 TINES




CULTIVATOR SIZE
13' CENTRE / 23'4" WIDE
6" TINE SPACING 47 TINES




CULTIVATOR SIZE
 13' CENTRE / 26'8" WIDE
 6" TINE SPACING 53 TINES



CULTIVATOR SIZE
13' CENTRE / 29'10" WIDE
6" TINE SPACING 59 TINES



CULTIVATOR SIZE
13' CENTRE / 33 1/2" WIDE
6" TINE SPACING 65 TINES



Notes: