

KONGSKILDE *spare parts list*

Listino di prezzi de ricambio

Lista de piezas de recambio

Liste de pièce de rechange

Reservedelsliste

Onderdelenlijst

Varaosaluettelo

Reservdelslista

Ersatzteilliste

JB

KONGSKILDE *spare parts list*

Model SRVF 209

211

310

313

304

306

09


13

REPLACEMENT MATERIAL


manual no 3 section 9

Replaces 05 018 066

10.9.81



SRVF 209/211/310/313/304/306/09 & 13



1:20

| Fig. No. | Pack No. | Serial No. | Part No. | Pcs. | Notes |
|----------|------------|------------|------------|------|-----------------------------|
| 1A | | | 05 018 015 | 1 | Type: SRVF 310/313/09 & 13 |
| 2A | | | 05 018 007 | 1 | Type: SRVF 209 & 211 |
| 3A | | | 00 333 031 | 1 | ∅10 x 56 |
| 4A | | | 00 316 006 | 2 | M16 |
| 5A | | | 03 010 045 | 1 | |
| 6A | | | 03 000 063 | 1 | |
| 7A | | | 00 306 070 | 1 | M20 x 100 |
| 8A | | | 05 018 013 | 1 | |
| 9A | | | 00 316 007 | 1 | M20 |
| 10A | | | 00 333 014 | 2 | ∅9,5 mm |
| 11A | | | 05 018 002 | 1 | |
| 12A | | | 03 010 040 | 2 | ∅19 x 85 |
| 13A | | | 00 306 071 | 2 | M12 x 35 |
| 14A | | | 00 306 058 | 1 | M16 x 60 |
| 15A | | | 05 015 023 | 1 | Type: SRVF 310 |
| 16A | | | 05 018 072 | 1 | Type: SRVF 209/211/313 & 13 |
| 17A | | | 05 019 028 | 1 | Type: SRVF 09 |
| 18A | | | 05 018 084 | 1 | |
| 19A | | | 05 018 083 | 1 | |
| 20A | | | 00 306 046 | 4 | M12 x 50 |
| 21A | | | 00 306 048 | 2 | M12 x 60 |
| 22A | | | 00 316 005 | 8 | M12 |
| 23A | | | 05 018 027 | 2 | |
| 24A | | | 00 306 045 | 2 | M12 x 45 |
| 25A | | | 05 013 003 | 1 | Type: SRVF 209 |
| 26A | | | 05 014 002 | 1 | Type: SRVF 211 |
| 27A | | | 05 015 006 | 1 | Type: SRVF 310 |
| 28A | | | 05 016 009 | 1 | Type: SRVF 313 |
| 29A | | | 05 019 001 | 1 | Type: SRVF 09 |
| 30A | 05 020 000 | | 05 020 001 | 1 | Type: SRVF 13 |
| 31A | | | 05 016 017 | 1 | Type: SRVF 211/313 & 13 |
| 32A | | | 05 016 018 | 1 | Type: SRVF 211/313 & 13 |
| 33A | 05 013 003 | | 05 013 012 | 1 | Type: SRVF 209 |
| 34A | 05 014 002 | | 05 014 008 | 1 | Type: SRVF 211 |
| 35A | 05 015 002 | | 05 015 012 | 1 | Type: SRVF 310 |
| 36A | 05 016 002 | | 05 016 016 | 1 | Type: SRVF 313 |
| 37A | 05 019 000 | | 05 019 012 | 1 | Type: SRVF 09 |
| 38A | 05 020 000 | | 05 020 010 | 1 | Type: SRVF 13 |
| 39A | 05 013 003 | | 05 013 011 | 1 | Type: SRVF 209 |
| 40A | 05 014 002 | | 05 014 007 | 1 | Type: SRVF 211 |
| 41A | 05 015 002 | | 05 015 011 | 1 | Type: SRVF 310 |
| 42A | 05 016 002 | | 05 016 015 | 1 | Type: SRVF 313 |
| 43A | 05 019 000 | | 05 019 009 | 1 | Type: SRVF 09 |
| 44A | 05 020 000 | | 05 020 007 | 1 | Type: SRVF 13 |
| 45A | | | 03 000 454 | | Fig. 33AB - 43AB Repair kit |
| 46A | | | 00 421 000 | | M6 |
| 47A | 05 017 000 | | 05 017 008 | 1 | Type: SRVF 304 |
| 48A | 05 017 011 | | 05 017 022 | 1 | Type: SRVF 306 |
| 49A | | | 01 010 120 | 4 | |
| 50A | | | 00 333 003 | 4 | ∅4 x 25 |
| 51A | | | 05 017 003 | 2 | |
| 52A | 05 017 000 | | 05 017 004 | 1 | Type: SRVF 304 |
| 53A | 05 017 011 | | 05 017 014 | 1 | Type: SRVF 306 |
| 54A | 05 017 000 | | 05 017 005 | 1 | Type: SRVF 304 |
| 55A | 05 017 011 | | 05 017 015 | 1 | Type: SRVF 306 |
| 56A | 05 017 000 | | 05 017 007 | 1 | Type: SRVF 304 |
| 57A | 05 017 011 | | 05 017 017 | 1 | Type: SRVF 306 |
| 58A | | | 00 414 009 | | |

KONGSKILDE
spare parts list
1981.04