


***CDS***



**Reservedelsliste  
Spare parts list  
Ersatzteilliste  
Onderdelenlijst  
Liste de pièce de rechange  
Lista dei pezzi di ricambio**

# CDS 17-11, 21-15, 25-17, 29-19 & 34-23




Fig.	Serial no.	Part no.	Pieces	Notes
1 2 3 4 7		103 018 001 103 018 000 103 018 006 103 018 007 103 091 011	1	"1000" for CDS 17-11, 21-15 & 34-23 "800" for CDS 17-11 "1200" for CDS 21-15, 25-17 & 34-23 "1400" for CDS 29-19 For CDS 17-11
8		103 092 009 103 093 009 103 094 008 103 095 023 100 316 004	1 1 1 1 12/16	For CDS 21-15 For CDS 25-17 For CDS 29-19 For CDS 34-23 Lock nut M10
9 10 11 12 13		100 306 032 100 306 030 103 000 268 100 316 005 103 090 041	4/8 8 1 2 2	Set screw M10 x 40 mm set screw M10 x 30 mm  Lock nut M12
14 15 16 17 18		103 090 042 100 306 044 100 316 005 100 333 014 103 010 144	2 2 2 1 1	Set screw M10 x 40 mm Lock nut M12 Lynch pin $\varnothing$ 9.5 mm $\varnothing$ 19 x 102 mm
19 20 21 22 23		103 090 058 100 306 044 100 304 033 100 315 016 103 090 026	2 4 2 2 2	Set screw M12 x 40 mm Set screw M12 x 35 mm Nut M12
24 25 26 27 28		103 090 038 100 331 007 100 306 044 100 333 011 103 090 059	2 2 2 2 1	Flat washer M12 Set screw M10 x 40 mm Hair pin split $\varnothing$ 4 mm
29 30 31 32 34		104 000 013 100 315 016 103 090 008 101 000 693 100 315 016	2 2 2 2 2	Nut M12   Nut M12
35 36 37 38 39		103 000 462 100 333 031 103 010 049 105 018 067 103 000 063	1 1 1 1 1	Split pin $\varnothing$ 10 x 56 mm
40 41 63 Cpl:		103 010 045 105 018 002 100 421 000 103 000 454	1 1 4/6 4/6	Grease nipple M6 Incl. items 55 - 65

