


TINE PATTERNS


For the standard 4" - 4 bar time spacing, mount tines at the positions shown for each cultivator size according to the tine pattern diagrams provided in this section of the assembly manual. NOTE: There are no dimensions given for tine placements on stub toolbars, only a star or dot is shown on the diagram. Tines placed on stub toolbars should be centred on the bar.

For Optional Tine Patterns, refer to the appropriate section in the "Tine Pattern Manual For Kongskilde Field Cultivators". The tine pattern manual provides diagrams for optional tine placements for 2600 Series cultivators, Front 5-Bar attachment, Nose Extensions and other 2600 Series cultivator attachments.

Note: High Clearance Tines must not be placed on centre sections or wings at the positions shown in figure 14. A special bolt-on tine bar at these locations has been designed to allow the standard "S" tine to be used instead of high tines.



2600 CENTER SECTION
 37 Standard Tines
 or
 2 Standard Tines & 35 Consortines




2614 CENTER SECTION


43 Standard Tines

or



2 Standard Tines & 41 Consortines



2 Standard Times & 43 Consertines



18' WINGS
4" - 16" Rear Row
8 Standard Tines Each



MODEL
2620/3520

TITLE



4 BAR 16" REAR TINE PATTERN

DATE:
12/93



SECTION
1

PAGE
7

20' WINGS
4" - 16" Rear Row
12 Standard Tines Each



23' WINGS
4" - 16" Rear Row
16 Standard Tines Each



25' WINGS
4" - 16" Rear Row
20 Standard Tines Each

