


6. Spare Part

EI-System



Position	Part number	Description
1	7002155779	Rotation guard
2	7000602943	Motor
2a	7000602953	Sensor for motor
3	7000603122	Sensor for blower
4	7000603120	Motor controlbox
5	7009603765	Level sensor
7	7000603119	Tractor cable incl. bracket
8	7000603088	Assembly kit consisting of pos. 8 - 10 - 14 - 15
9	7000603087	LH 5000 monitor
		Connection to batteri, part of pos. 8
11	7009603555	7 leads alternative plug (male)
12	7000603269	Implement sensor
13	7000603070	Wheel sensor for tractor
14		Junction box, part of pos. 8
15	7009603556	7 leads alternative plug (female)
17	7000603072	Junction box
17a	7000603509	Print for tramline valves
17b	7000602980	Relay 12 V
18		Part of pos. 17
19	7000603269	Implement sensor