




KONGSKILDE *spare parts list*


FUVF




FURVF



FULVF



Type: FUVF 205 Pack: 05 071 012		Type: FUVF 207 Pack: 05 071 013		Type: FUVF 209 Pack: 05 071 014		Type: FUVF 211 Pack: 05 071 015		Type: FUVF 313/13 Pack: 05 072 017		Type: FUVF 306 Pack: 05 072 020		Date: 1994.05
Type: FUVF 310 Pack: 05 072 016		Type: FUVF 09 Pack: 05 074 003		Type: FUVF 300 Pack: 05 072 018		Type: FUVF 304 Pack: 05 072 019		Type: FUVF 306 Pack: 05 072 020		Type: FUVF 306 Pack: 05 072 020		
Fig. No.	Pack No.	Serial No.		Part No.	Pcs.	Notes						
32				00 316 005		M12						
50				05 070 019		M16						
51				00 316 006		M16						
52				05 070 033		M8 x 15						
53				00 306 014		M8						
54				05 070 059		M8						
55				00 316 003		M12 x 35						
56				00 306 071								
57				05 070 034		No. 6205 - 2 RS						
58				00 401 032								
59				05 070 030								
60				05 070 038								
61				05 070 037								
62				05 070 036								
63				05 070 035								
64				05 070 040								
66				05 070 039								
67				05 070 024								
68				05 070 012								
80				05 072 012		f. 300						
81				05 072 001		f. 304						
82				05 072 002		f. 306						
83				05 071 003		f. 205						
84				05 071 005		f. 207						
85				05 071 001		f. 209						
86				05 072 007		f. 211						
87				05 072 005		f. 310						
88				05 072 007		f. 313/13						
89				05 074 001		f. 09						
103				00 414 009								
120				00 333 014		ø9,5 mm						
121				05 000 388		M16						
123				00 331 008		ø9/65 x 380 mm f. 304						
124				05 070 060		ø11/75 x 380 mm f. 306						
125				05 070 062		f. 304 & 305						
126				05 070 063								
127				05 070 048								
128				05 070 053		M16 x 45						
129				00 306 056								
132				05 070 068								
133				00 306 071		M12 x 35						
134				00 302 038		M16 x 110 w. nut						
135				03 010 128		M6						
136				00 421 000								
137				03 010 049								
138				05 070 073								
139				03 000 063								
140				03 010 045								
141				05 018 002								
142				05 018 013								
143				00 306 070		M20 x 100						
144				00 316 007		M20						
145				05 018 007		f. 205, 207, 209 & 211						
146				05 018 015		f. 310, 313/13 & 09						
147				00 333 031		ø10 x 56 mm						
148				05 018 084		ø9,5 mm						
149				00 333 014								
150				03 010 040								
152				05 018 083		M12 x 50						
153				00 306 046								



KONGSKILDE						Date: 1994.05					
spare parts list											
Fig. No.	Pack No.	Serial No.	Part No.	Pcs.	Notes	Type: FURVF 205 Pack: 05 071 512	Type: FURVF 207 Pack: 05 071 513	Type: FURVF 209 Pack: 05 071 514	Type: FURVF 211 Pack: 05 071 515	Type: FURVF 313/13 Pack: 05 072 517	Type: FURVF 306 Pack: 05 072 520
1			03 000 486		"R"						
2			03 000 487		"L"						
4			03 000 488		"1000"						
5			03 000 489		"900"						
6			03 000 437		"600"						
CPL.			03 000 454		Fig. 7 - 17. Repair kit						
15			00 421 000		M6						
18			00 306 058		M16 x 60						
19			01 000 624								
20			00 306 093		M16 x 130						
21			05 075 027								
23			05 075 028								
32			00 316 005		M12						
50			05 070 019		M16						
51			00 316 006								
52			05 070 033								
53			00 306 014		M8 x 15						
54			05 070 059		M8						
55			00 316 003		M8						
56			00 306 071		M12 x 35						
57			05 070 034								
58			00 401 032		No. 6205 - 2 RS						
59			05 070 030								
60			05 070 038								
61			05 070 037								
62			05 070 036								
63			05 070 035								
64			05 070 040								
66			05 070 039								
67			05 070 024								
68			05 070 012								
90			05 072 511		f. 300						
91			05 072 505		f. 304						
92			05 072 501		f. 306						
93			05 072 512		f. 300						
94			05 072 506		f. 304						
95			05 072 502		f. 306						
96			05 071 504		f. 205						
97			05 071 507		f. 207						
98			05 071 501		f. 209						
99			05 071 510		f. 211						
100			05 072 507		f. 310						
101			05 072 509		f. 313/13						
102			05 074 501		f. 09						
103			00 414 009								
120			00 333 014		ø9.5 mm						
121			05 000 388								
123			00 331 008		M16						
124			05 070 060		ø9/65 x 380 mm f. 300 & 304						
125			05 070 062								
126			05 070 063		ø117/5 x 380 mm f. 306						
127			05 070 048								
128			05 070 053								
129			00 306 056		M16 x 45						
132			05 070 068								
133			00 306 071		M12 x 35						
134			00 302 036		M16 x 110 w. nut						
135			03 010 128		M6						
136			00 421 000								
137			03 010 049								
138			05 070 073								
139			03 000 063								
140			03 010 045								
141			05 018 002								
142			05 018 013								
143			00 306 070		M20 x 100						
144			00 316 007		M20						
145			05 018 007		f. 206, 207, 209 & 211						
146			05 018 015		f. 310, 313/13 & 09						
147			00 333 031		ø10 x 56 mm						
148			05 015 084								
149			00 333 014		ø9.5 mm						
150			03 010 040								
152			05 018 083								
153			00 306 046		M12 x 50						






Fig. No.	Pack No.	Serial No.	Part No.	Pcs.	Notes
18	Type: FULVF 205 Pack: 05 071 512	Type: FULVF 207 Pack: 05 071 513	Type: FULVF 209 Pack: 05 071 514	Type: FULVF 211 Pack: 05 071 515	Type: FULVF 313/13 Pack: 05 072 517
19	Type: FULVF 310 Pack: 05 072 516	Type: FULVF 09 Pack: 05 074 502	Type: FULVF 300 Pack: 05 072 518	Type: FULVF 304 Pack: 05 072 519	Type: FULVF 306 Pack: 05 072 520
20					
21					
25					
26					
27					
28					
29					
30					
31					
32					
33					
34					
35					
36					
37					
38					
39					
40					
41					
42					
43					
44					
45					
46					
47					
48					
49					
50					
51					
52					
53					
54					
55					
56					
57					
58					
59					
60					
61					
62					
63					
64					
65					
66					
67					
68					
69					
70					
71					
72					
73					
74					
75					
76					
77					
78					
79					
80					
81					
82					
83					
84					
85					
86					
87					
88					
89					
90					
91					
92					
93					
94					
95					
96					
97					
98					
99					
100					
101					
102					
103					
104					
105					
106					
107					
108					
109					
110					
111					
112					
113					
114					
115					
116					
117					
118					
119					
120					
121					
122					
123					
124					
125					
126					
127					
128					
129					
130					
131					
132					
133					
134					
135					
136					
137					
138					
139					
140					
141					
142					
143					
144					
145					
146					
147					





KONGSKILDE MASKINFABRIK A/S . DK-4180 SORØ , DANMARK



FUVF



FURVF



FULVF



FUVE 313P, 312P, 13H, 08 & 12





Fig. No.	Pack No.	Serial No.	Part No.	Pcs.	Notes	Type: FUVE 313 P Pack: 05 073 034	Type: FUVE 312 P Pack: 05 073 036	Type: FUVE 13 H Pack: 05 073 035	Type: FUVE 08 Pack: 05 073 037	Type: FUVE 12 Pack: 05 073 038	KONGSKILDE spare parts list	Date: 1984.05
32			00 316 005		M12							
50			05 070 019		M16							
51			00 316 006		M8 x 15							
52			05 070 033									
53			00 306 014									
54			05 070 059		M8							
55			00 316 003		M12 x 35							
56			00 306 071									
57			05 070 034									
58			00 401 032		No. 6205 - 2 RS							
59			05 070 030									
60			05 070 038									
61			05 070 037									
62			05 070 036									
63			05 070 035									
64			05 070 040									
66			05 070 039									
67			05 070 024									
68			05 070 012									
103			00 414 009									
104			05 073 001		f. 313 P							
105			05 073 031		f. 13 H							
106			05 073 016		f. 312 P							
107			05 073 029		f. 08							
108			05 073 025		f. 12							
109			05 073 017		f. 312 P							
110			05 073 027		f. 08							
111			05 073 023		f. 12							
160			05 073 032		f. 312 P							
161			05 073 006		f. 08 & 12							
162			00 316 005		M12							
163			00 306 071		M12 x 35							
164			05 073 052									
165			00 316 005		M12							
166			05 073 022									
167			00 333 011		ø4 mm							
168			05 023 037		ø14,6 x 135 mm							
169			00 306 046		M12 x 50							
170			04 000 013									
171			05 073 045									
172			05 073 010		M12							
173			00 316 005									
174			05 073 009									
175			04 000 004		M16							
176			00 331 021									
177			00 316 006		M16							
178			00 307 039		M16 x 140							
179			01 091 034									
180			00 306 044		M12 x 40							

A diagram showing a hand holding a wire that forms a loop. The wire passes through a series of rectangular blocks. A line labeled 'B' represents a magnetic field line, and a line labeled 'I' represents the current. The wire is labeled '1' and '2' at different points.



KONGSKILDE MASKINFABRIK A/S . DK-4180 SORØ . DANMARK

FULVF 313P, 312P, 13H, 08 & 12




Fig. No.	Pack No.	Serial No.	Part No.	Pcs.	Notes	Type: FULVF 313 P Pack: 05 073 514	Type: FULVF 312 P Pack: 05 073 516	Type: FULVF 13 H Pack: 05 073 515	Type: FULVF 08 Pack: 05 073 517	Type: FULVF 12 Pack: 05 073 518	Date: 1984.05
18			00 306 038		M16 x 60						
19			00 306 039		M16 x 130						
20			00 306 040								
21			05 075 022								
26			05 075 013		M12 x 90						
27			00 306 051		M12 x 40						
28			00 304 034		M12						
29			00 331 007								
30			05 075 014								
31			21 134 244								
32			00 316 005		M12						
33			00 304 032		M12 x 30						
34			05 075 009								
35			02 200 004								
36			00 315 009		M12						
41			02 233 001		L = 560 mm						
42			02 252 008		L = 760 mm						
43			02 234 001		L = 860 mm						
44			02 253 017		L = 1160 mm						
45			02 200 024		L = 1260 mm						
50			05 070 019		M16						
51			00 316 006								
52			05 070 033		M8 x 15						
53			00 306 014								
54			05 070 059		M8						
55			00 316 003		M8 x 35						
56			00 306 071		M12 x 35						
57			05 070 034		No. 6205 - 2 RS						
58			00 401 032								
59			05 070 030								
60			05 070 038								
61			05 070 037								
62			05 070 036								
63			05 070 035								
64			05 070 040								
66			05 070 039								
67			05 070 024								
68			05 070 012								
103			00 414 009								
112			05 073 504		f. 313 P						
113			05 073 505		f. 13 H						
114			05 073 500		f. 312 P						
115			05 073 506		f. 08						
116			05 073 510		f. 12						
117			05 073 501		f. 312 P						
118			05 073 508		f. 08						
119			05 073 512		f. 12						
160			05 073 032		f. 312 P						
161			05 073 006		f. 08 & 12						
162			00 316 005		M12						
163			00 306 071		M12 x 35						
164			05 073 052								
165			00 316 005		M12						
166			05 073 022								
167			00 333 011		ø4 mm						
168			05 023 037		ø14,6 x 135 mm						
169			00 306 046		M12 x 50						
170			04 000 013								
171			05 073 045								
172			05 073 010		M12						
173			00 316 005								
174			05 073 009		M16						
175			04 000 004								
176			00 331 021		M16						
177			00 316 006		M16 x 140						
178			00 302 039								
179			01 091 034		M12 x 40						
180			00 306 044								